



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp




PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk



Novotechnik


Enapart は常に、顧客に最高の価格と供給のタイミングを提供するよう努めています。弊社は、必ずしも公式の販売代理店または製造業者ではありませんが、OEMとスペアパーツのみを販売しています。表示されているすべての商標および部品番号は、それぞれの所有者に帰属します。

ブランド商品

商品名	説明
0050-415-002-101	ポジショントランスデューサ
P/N: 019522 Type: SP-2801-100-002-001	角度ポテンシオメータ位置センサ 100° 3kOhm
P/N: 400023262 Type: TR-0050	連続プッシュロッドを備えた最大100 mmの距離センサー
026112 / LWG-0300	
051409/A	
WEGTASTER,STECKBAR,LP	
ART.NO 024307 LWH-0175	Transducer
400005323	非接触変位センサ、誘導
ART.NO. 005634 EEM-33-89	
400005636 / EEM 33-91	W-DOSE
Art.No. 005697 Z-TH1-P18	
P-6501-A502.025	ROUNDポテンシオメータ
P/N: 400019520 Type: SP-2801-308-000-001	ロータリーセンサポテンシオメータ
019521, Type: SP-2831-308-000-001	センサポテンシオメータ
RSC-2801-610-112-210	角度センサー、非接触
400023236 / TS-0150	リニアトランスデューサ
ART.NO. 024313 LWH-0325	transducer
ART.NO. 025304 TLH-0100	Transducers, potentiometric
Art.No. 025309 TLH-0225	コンロッド無しトランスデューサ
P/N: 400025312, Type: TLH-0300	トランスデューサ (プッシュロッドなし)
ART.NO. 025314 TLH-0360	プッシュロッドなしの変位センサー
P/N: 400025332, Type: TLH-0800	transducer
P/N: 400025335, Type: TLH-0875	position sensor
002535 Type: TLH 1100	電位差計
400025354 / TLH-1350	トランスデューサ (プッシュロッドなし)
ART.NO. 025364 TLH-1600	プッシュロッドなしのトランスデューサ
400026109 / LWG-0225	直線定規
ART.NO. 026154 LWX-0150-001	ポジショントランスデューサ
TH1-1400-102-423-102	変換器
Art.No. 4000420AH, Type: TH1-0500-102-423-102	VZTYP ENCODED
400054014 / MUP-110-4	ポテンシオメータトランスデューサ
ART.NO. 054103 MUW-200-4	Signal Conditioners for LWH and TLH Transducers
400010018	potentiometer
Art.-Nr.: 005698 Z-TH1-P19	



商品名	説明
p/n: 400008218, Type: P-6501-4007	ポテンショメータ
Art.No. 400011021, Type AW-360-ZE-10	円形ポテンショメータ
400005627 / EEM 33-84	コネクタ
400005323 / F-210 G	トランスデューサ非接触、誘導
FTI 10	
GP5 REF. 98103454	potentiometer position
400010001 / IP-6501-A502	産業用ロータリー・センサー・ポテンショメータ
P/N: 400010061 Type: IPS-6501-A502	位置センサー
Art.No. 026109 Type 026109	トランスデューサ
400026106 / LWG-0150	トランスデューサ
LWG-0360	リニアポテンショメータ位置センサ
LWH 0250 / 400024510	ENCODED
P/N: 400024312 Type: LW-0300	STROKEトランスデューサ
LWH-0130 / 400024505	
400024506 / LWH-0150	位置トランスデューサ
P/N: 400024307 Type: LWH-0175	Art.Nr:024307 F.Nr:110366/G
400024313 / LWH-0325	探触子、電位差計、LWHシリーズ
P/N: 024318 Type: LWH-0450	ポジショントランスデューサ
LWH-0450	プッシュロッド付き変位センサー
400024306 / LWH-0150	トランスデューサー、電位差、LWHシリーズ
400024307 / LWH-0175	ポジショントランスデューサ
Art.No. 024309 LWH-0225	プッシュロッドとトランスデューサ
Art.No. 024312, LWH-0300	プッシュロッドとトランスデューサー
Art.No. 24314, Type LWH-0360	トランスデューサー、電位差、LWHシリーズ
Art.No. 024318, Type: LWH-0450	プッシュロッドとトランスデューサー
P/N: 400026187 Type: LWX-0300-002	ポジショントランスデューサ
MAP 4000 210 101	インジケータ24V
P/N: 400054153 Type: MUW-250-4	送信機
400006203 / P-4501-A502	ポテンショメータ
00107682	
P-6501-A102	標準ポテンショメータ
Art.No.:008203 / P-6501-A502	電位差計
400008203 / P-6501-A502	ロータリーセンサー/ポテンショメータ
RFC-4801-618-321-201	Magnetic Rotary Sensors
241924 / RFC 4801-636-321-251	SENSOR
RFC-4801-609-111-201 obsolete	
RFC-4801-603-111-201	Linear Transducer
RFC-4801-xxx-xxx-xxx	角度センサー
RFC-4801-611-121-202	センサー
RFC-4801-636-111-201	
RFC-4801-636-211-206	ANGLEセンサータッチレス 商品番号：040AAV
RFC-4801-636-211-401	角度センサー、非接触、透過型



商品名	説明
RFC-4801-636-321-401	角度センサー
RFC-4801-636-341-551	ロータリーセンサー
RFC-48xx-6xx-121-xxx	B/N:131489/009
RSC-2801-610-211-201	角度センサー、非接触式、RSCシリーズ
RSC 2801 636 111 210	角度センサー
RSC-2801-610-112-201	角度センサー、非接触型、RSCシリーズ
SP-2801-100-002-001	センサーポテンシオメータ
P/N: 400019522 Type: SP-2801-100-002-001	センサーポテンシオメータ
Art.No. 019520, SP-2801-308-000-001	センサ、ポテンシオメータ
400019527 / SP-2831-100-002-001	センサ、ポテンシオメータ
SP2831308 000 009,ART.NR. 019547 OEM for SIPOS	ロータリセンサポテンシオメータ
SP-2831-308-000-001	フランジ加工機センサー
400023203 / T-0050	変位センサー
TEX 0010	リニアポテンシオメータ
TEX-0100-415-002-101	プッシュロッド
TEX-0025-415-002-202	位置トランスデューサ、電位差計、TEX、TX2シリーズ
P/N: 025320 Type: TLH-0500	
Art.No. 025305, Type TLH-0130	リニアポテンシオメータ
P/N: 400025360, Type: TLH-1500	位置トランスデューサ
TLH-0200 025308	Art.Nr : 025308
025309	リニアポテンシオメータ
400025312 / TLH-0300	
400025318 / TLH-0450	位置変換器
TLH-0525	位置トランスデューサ
TLH-0600	プッシュロッドなしの変位センサー
P/N: 400025326, Type: TLH-0650	位置トランスデューサ
Art.No. 025335, Type: TLH-0875	プッシュロッドなしのトランスデューサ
P/N: 400025338 Type: TLH-0950	位置トランスデューサ
P/N: 025350 Type: TLH-1250	
Art.No. 025336 / TLH-0900	コンロッド無しトランスデューサ
TP1-0300-101-411-205	100292/11070130
TP1-0500-101-411-205	磁歪位置定規
TP1-0600-101-411-205	リニアルーラー
TP1-0750-101-423-101	変位センサー
TR-0025	連続プッシュロッド付きの100mmまでの距離センサー
400023271 / TRS-0025	押しボタン、プラグ可能
Art.No. 023271, Type: TRS-0025	トランスデューサ
400023272 / TRS-0050	トランスデューサ
Typ LWH-0750 / Art.N.400024330	電位差測定変位トランスデューサ LWH シリーズ
P/N: 400005693 Type: Z-TP1-P06	ポジションインジケータ
Z-TP1-P06	POSドナーTP1 FREE-04ミリメートル
P/N: 400005695, Type: Z-TP1-P08	ポジション提供者



商品名	説明
Z-TP1-S01-0800	PUSH ROD TLM / TP1
P/N: 400006202 Type: P-4501-A202	Rundpotentiometer
P/N: 400006202, Type: P-4501-A202	ロータリーセンサー
024336 / LWH-0900 old code - new code 400024536 / LWH-0900	トランスデューサー、電位差
400054173 / MUK 350-4	ポテンショメータ用計測コンバータ
Art.No. 023262 / TR-0050	連続スライディングロッド100ミリメートルトランスデューサー
TH1-1500-104-423-102	トランスデューサー
Z-TH1-P18 POS SENSOR TH1-18 RING Ø12 / 25	
Art.No. 008201 / P-6501-A102	電位差計
P/N: 400002220 Type: P-2201-S0031	RUNDPOTENTIOMETER
Art.No. 025330 / TLH-0750	トランスデューサー、電位差、TLHシリーズ
P/N: 400024306, Type: LWH-0150	プッシュロッドとトランスデューサー
RSM 2831-010-111-206.	トランスデューサー
TR100	リニアトランスデューサー
TR25	リニアトランスデューサー
40003900B) RFA-4001-636-211-401	ストアSENSOR
RFC-4801-636-211-202	ロータリーセンサー
P/N: 400005658 Type: Z-RFC-P03	POSゲベル
TEX-0050-415-002-202	トランスデューサー、電位差
Art.No. 005627 / EEM-33-84	接続技術
Z-TH1-P19 POS-GEBER TH1-19 RING Ø13/32	ポジションマーカ
024304 / LWH-0100	プッシュロッド付き変位センサー
400024530 / LWH-0750	トランスデューサー
Art.No. 024309, Type LWH-0225	トランスデューサー、電位差、LWHシリーズ
Art.No. 024304, Type LWH-0100	トランスデューサー、電位差、LWHシリーズ
P/N: 400008203, Type: P-6501-A502	角度センサ、電位差計、Pシリーズ
Art.No. 025330, Type TLH-0750	プッシュロッドなしのトランスデューサー
P/N: 400025312 Type: THL-0300	位置トランスデューサー
LS1-0075-001-421-101	トランスデューサー
Art.No. 024312, Type: LWH-0300	プッシュロッドとトランスデューサー
Art.No. 025324, Type: TLH-0600	プッシュロッドなしの変位センサー
Art. Nr.400023271 Type TRS-0025	トランスデューサー、STECKBAR
P/N: 400026109 Type: LWG-0225	変位センサー
40003700W / TEX-0200-413-002-101	ENCODED
RFC4800	センサー
400025312, Type: TLH-0300	電位差センサー
Art.No. 400024560, Type: LWH-0110	プッシュロッド付き変位センサー
Art.No. 019520, Type: SP-2801-308-000-001	センサ、ポテンショメータ
Art.No. 400049651, Type: TE1-0050-102-411-101	電位差測定式ポジションスイッチ
TE1-0025-102-411-101	
Art.No. 400023233, Type: TS-0050	トランスデューサー、STECKBAR



商品名	説明
025312, Type: TLH-0300	potentiometer
Art.No. 023235, Type: TS-0100	トランスデューサ
4000420KM / TH1-0200-102-423-102	VZTYP 位置検出器
400024311	トランスデューサ
400024314	トランスデューサ
400024324	トランスデューサ
TH1-1400-104-423-102	トランスデューサ
P/N: 024311 Type: LWH-0275	
P/N: 058001 Type: Z301-M6/M6	
Art.No. 53105, Type: FTI-10.1.50.0. K1	トランスデューサ非接触、誘導
400053101 / FTI-10.1.50.4. K1	トランスデューサ非接触、誘導
Art.No. 53107, Type: FTI-10.1.67.0. K1	トランスデューサ非接触、誘導
P/N: 400053103, Type: FTI-10-1-67-4-K1	ポジショントランスデューサ
400053104 / FTI-10.2.50.0. K1	トランスデューサ非接触、誘導
Art.No. 53100, Type: FTI-10.2.50.4. K1	非接触位置センサー、誘導式
Art.No. 53106, Type: FTI-10.2.67.0. K1	トランスデューサ非接触、誘導
Art.No. 53102, Type: FTI-10.2.67.4. K1	トランスデューサ非接触、誘導
Art.No. 53114, Type: FTI-10.4.50.0. K1	トランスデューサ非接触、誘導
Art.No. 53110, Type: FTI-10.4.50.4. K1	トランスデューサ非接触、誘導
Art.No. 53116, Type: FTI-10.4.67.0. K1	トランスデューサ
Art.No. 53112, Type: FTI-10.4.67.4. K1	トランスデューサ非接触、誘導
Art.No. 5303, Type: F-205 G P/N: 400005304 Type: F-205.1G	トランスデューサ非接触、誘導
Art.No. 5323, Type: F-210 G	トランスデューサ非接触、誘導
Art.No. 5324, Type: F-210.1G	トランスデューサ非接触、誘導
P/N: 400005325, Type: F-220 G	非接触位置センサ、誘導型
Art.No. 5693, Type: Z-TP1-P06 400005694	シリーズのための位置センサ (PG) pos.donor 無誘導な
Art.No. 56044, Type: Z-TH1-P21	シリーズのための位置センサ (PG)
Art.No. 56045, Type: Z-TH1-P22	シリーズのための位置センサ (PG)
Art.No. 5697, Type: Z-TH1-P18	シリーズのための位置センサ (PG)
Art.No. 5698, Type: Z-TH1-P19	シリーズのための位置センサ (PG)
Art.No. 5699, Type: Z-TIM-P20	シリーズのための位置センサ (PG)
Art.No. 104225, Type: Z-TFC-P03	シリーズのための位置センサ (PG)
Art.No. 104226, Type: Z-TFC-P04	シリーズのための位置センサ (PG)
Art.No. 5602, Type: EEM-33-56	シリーズの接続技術M8x1
Art.No. 5604, Type: EEM-33-58	シリーズの接続技術M8x1



商品名	説明
400005606 / EEM-33-60	シリーズ用M8x1接続テクノロジー
Art.No. 5603, Type: EEM-33-57	シリーズの接続技術M8x1
Art.No. 5605, Type: EEM-33-59	シリーズの接続技術M8x1
Art.No. 5607, Type: EEM-33-61	シリーズの接続技術M8x1
Art.No. 5633, Type: EEM-33-88	シリーズ用M12x1接続技術
Art.No. 5634, Type: EEM-33-89	シリーズ用M12x1接続技術
Art.No. 56141, Type: EEM-33-41	シリーズ用M12x1接続技術
Art.No. 56142, Type: EEM-33-42	シリーズ用M12x1接続技術
Art.No. 56143, Type: EEM-33-43	シリーズ用M12x1接続技術
Art.No. 56144, Type: EEM-33-44	シリーズ用M12x1接続技術
Art.No. 5645, Type: EEM-33-73	シリーズ用M12x1接続技術
Art.No. 5646, Type: EEM-33-75	シリーズ用M12x1接続技術
Art.No. 56145, Type: EEM-33-45	シリーズ用M12x1接続技術
Art.No. 56147, Type: EEM-33-47	シリーズ用M12x1接続技術
Art.No. 5629, Type: EEM-33-86	シリーズ用M12x1接続技術
Art.No. 5635, Type: EEM-33-90	シリーズ用M12x1接続技術
400005637 / EEM-33-92	接続テクノロジー
Art.No. 5630, Type: EEM-33-87	シリーズ用M12x1接続技術
Art.No. 5636, Type: EEM-33-91	シリーズ用M12x1接続技術
Art.No. 5638, Type: EEM-33-93	シリーズ用M12x1接続技術
Art.No. 56131, Type: EEM-33-01	シリーズ用M12x1接続技術
P/N: 400005639, Type: EEM-33-82	接続技術
Art.No. 5648, Type: EEM-33-94	シリーズの接続技術M16x0.75 IEC130-9、
Art.No. 56126, Type: EEM-33-26	シリーズの接続技術M16x0.75 IEC130-9、
Art.No. 56127, Type: EEM-33-27	シリーズの接続技術M16x0.75 IEC130-9、
Art.No. 5627, Type: EEM-33-84	シリーズの接続技術M16x0.75 IEC130-9、
P/N: 400005628, Type: EEM-33-85	接続テクノロジー
Art.No. 56090, Type: Z-TH1-M01	ロックナット
Art.No. 56091, Type: Z-TH1-M02	シリーズのためのロックナット
Art.No. 56033, Type: Z-G02	ボールジョイントヘッドシリーズ
400005678 / Z-R50	シリーズ用測定子ローラー
Art.No. 56029, Type: Z-TP1-B03	シリーズのカニ
Art.No. 59010, Type: Z-FTI-B01	シリーズのカニ
Art.No. 56050, Type: Z-TP1-S01-007	位置センサー用プッシュロッド
Art.No. 56051, Type: Z-TP1-S01-010	位置センサー用プッシュロッド
Art.No. 56052, Type: Z-TP1-S01-012	位置センサー用プッシュロッド
Art.No. 56053, Type: Z-TP1-S01-015	位置センサー用プッシュロッド
Art.No. 56054, Type: Z-TP1-S01-020	位置センサー用プッシュロッド
Art.No. 56055, Type: Z-TP1-S01-025	位置センサー用プッシュロッド
Art.No. 56056, Type: Z-TP1-S01-030	位置センサー用プッシュロッド
Art.No. 56057, Type: Z-TP1-S01-035	位置センサー用プッシュロッド
Art.No. 56058, Type: Z-TP1-S01-040	位置センサー用プッシュロッド
Art.No. 56059, Type: Z-TP1-S01-045	位置センサー用プッシュロッド
Art.No. 56060, Type: Z-TP1-S01-050	位置センサー用プッシュロッド
Art.No. 56061, Type: Z-TP1-S01-060	位置センサー用プッシュロッド



商品名	説明
Art.No. 56062, Type: Z-TP1-S01-080	位置センサー用プッシュロッド
Art.No. 56063, Type: Z-TP1-S01-100	位置センサー用プッシュロッド
Art.No. 56064, Type: Z-TP1-S01-150	位置センサー用プッシュロッド
Art.No. 56065, Type: Z-TP1-S01-200	位置センサー用プッシュロッド
400023202 / T-0025	変位トランスデューサ
Art.No. 23207, Type: T-0025-.1	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23203, Type: T-0050	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23208, Type: T-0050-.1	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23209, Type: T-0050-.05	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23204, Type: T-0075	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23213, Type: T-0075-.05	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23205, Type: T-0100	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23214, Type: T-0100-.05	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23206, Type: T-0150	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23215, Type: T-0150-.05	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23232, Type: TS-0025	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23237, Type: TS-0025-.1	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23238, Type: TS-0050-.1	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23239, Type: TS-0050-.05	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23234, Type: TS-0075	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23243, Type: TS-0075-.05	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23235, Type: TS-0100	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23244, Type: TS-0100-.05	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23236, Type: TS-0150	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23245, Type: TS-0150-.05	連続したプッシュロッドで150 mmのトランスデューサ
Art.No. 23260, Type: TR-0010	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23261, Type: TR-0025	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23265, Type: TR-0025-.1	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23262, Type: TR-0050	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23266, Type: TR-0050-.1	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23267, Type: TR-0050-.05	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23263, Type: TR-0075	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23268, Type: TR-0075-.05	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23264, Type: TR-0100	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23269, Type: TR-0100-.05	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23271, Type: TRS-0025	連続的なプッシュロッドと100mmと最大トランスデューサ
400023275 / TRS-0025-1	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23276, Type: TRS-0050-.1	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23277, Type: TRS-0050-.05	連続的なプッシュロッドと100mmと最大トランスデューサ
400023278 / TRS-0075-05	連続的なプッシュロッドと100mmと最大トランスデューサ
Art.No. 23279, Type: TRS-0100-.05	連続的なプッシュロッドと100mmと最大トランスデューサ
Type: TE1-0025	変位トランスデューサ
Type: TE1-0050	変位トランスデューサ
Type: TE1-0075	変位トランスデューサ
Type: TE1-0100	変位トランスデューサ



商品名	説明
Type: TE1-0150	変位トランスデューサ
400037101 / TX2-0025-716-002-101	変位トランスデューサ
Art.No. 37102, Type: TX2-0050-716-002-101	スイベルヘッドと300ミリメートルのトランスデューサー
400037103 / TX2-0075-716-002-101	モーションセンサー
P/N: 400037104, Type: TX2-0100-716-002-101	モーションセンサー
Art.No. 37106, Type: TX2-0150-716-002-101	スイベルヘッドと300ミリメートルのトランスデューサー
400037108 / TX2-0200-716-002-101	スイベルヘッドと300ミリメートルのトランスデューサー
Art.No. 37109, Type: TX2-0250-716-002-101	スイベルヘッドと300ミリメートルのトランスデューサー
p/n: 37110, Type: TX2-0300-716-002-101	変位トランスデューサ
Art.No. 37201, Type: TX2-0025-716-002-202	変位トランスデューサ
400037202 / TX2-0050-716-002-202	スイベルヘッドと300ミリメートルのトランスデューサー
Art.No. 37203, Type: TX2-0075-716-002-202	スイベルヘッドと300ミリメートルのトランスデューサー
400037204 / TX2-0100-716-002-202	変位トランスデューサ
P/N: 400037206, Type: TX2-0150-716-002-202	最大300 mmの変位センサー、ジョイントヘッド付き、2 mラジアルケーブル
Art.No. 37208, Type: TX2-0200-716-002-202	スイベルヘッドと300ミリメートルのトランスデューサー
P/N: 37209 Type: TX2-0250-716-002-202	
Art.No. 37210, Type: TX2-0300-716-002-202	スイベルヘッドと300ミリメートルのトランスデューサー
P/N: 400037301, Type: TX2-0025-717-002-101	位置トランスデューサ
Art.No. 37302, Type: TX2-0050-717-002-101	取付ブロック300 mmのトランスデューサ
Art.No. 37303, Type: TX2-0075-717-002-101	取付ブロック300 mmのトランスデューサ
Art.No. 37304, Type: TX2-0100-717-002-101	取付ブロック300 mmのトランスデューサ
Art.No. 400037308, Type: TX2-0200-717-002-101	取付ブロック300 mmのトランスデューサ
400037309 / TX2-0250-717-002-101	最大300 mmの変位センサー、取り付けブロック付き
P/N: 400037310, Type: TX2-0300-717-002-101	POSITION TRANSDUCER
Art.No. 37401, Type: TX2-0025-717-002-202	取付ブロック300 mmのトランスデューサ
Art.No. 37402, Type: TX2-0050-717-002-202	取付ブロック300 mmのトランスデューサ
Art.No. 37403, Type: TX2-0075-717-002-202	取付ブロック300 mmのトランスデューサ
Art.No. 37404, Type: TX2-0100-717-002-202	取付ブロック300 mmのトランスデューサ




商品名	説明
Art.No. 37406, Type: TX2-0150-717-002-202	取付ブロック300 mmのトランスデューサ
Art.No. 37408, Type: TX2-0200-717-002-202	取付ブロック300 mmのトランスデューサ
Art.No. 37409, Type: TX2-0250-717-002-202	取付ブロック300 mmのトランスデューサ
Art.No. 37410, Type: TX2-0300-717-002-202	取付ブロック300 mmのトランスデューサ
Art.No. 26102, Type: LWG-0050 p/n 400026103, Type: LWG-0075	プッシュロッドとロッドの端部を有するトランスデューサ トランスデューサ
Art.No. 26106, Type: LWG-0150 400026107 / LWG-0175	ポジショントランスデューサ プッシュロッドとロッドの端部を有するトランスデューサ
Art.No. 26109, Type: LWG-0225	プッシュロッドとロッドの端部を有するトランスデューサ
Art.No. 26110, Type: LWG-0250	プッシュロッドとロッドの端部を有するトランスデューサ
Art.No. 26114, Type: LWG-0360 400026118 / LWG-0450	プッシュロッドとロッドの端部を有するトランスデューサ プッシュロッドとロッドの端部を有するトランスデューサ
400026122 / LWG-0550	プッシュロッドとロッドの端部を有するトランスデューサ
P/N: 400026124 Type: LWG-0600	トランスデューサ
P/N: 026130 Type: LWG-0750	プッシュロッドとロッドの端部を有するトランスデューサ
Art.No. 400026202, Type: LWG-0050-000-201	プッシュロッドとロッドの端部を有するトランスデューサ
Art.No. 26203, Type: LWG-0075-000-201	変位トランスデューサ
Art.No. 26206, Type: LWG-0150-000-201	プッシュロッドとロッドの端部を有するトランスデューサ
p/n: 26207, Type: LWG-0175-000-201	
Art.No. 26209, Type: LWG-0225-000-201 400026210 / LWG-0250-000-201	プッシュロッドとロッドの端部を有するトランスデューサ プッシュロッドとロッドエンドを備えた変位センサー
Art.No. 26212, Type: LWG-0300-000-201 400026214 / LWG-0360-000-201	プッシュロッドとロッドの端部を有するトランスデューサ 変位トランスデューサ
Art.No. 26218, Type: LWG-0450-000-201	プッシュロッドとロッドの端部を有するトランスデューサ
Art.No. 26220, Type: LWG-0500-000-201	プッシュロッドとロッドの端部を有するトランスデューサ
Art.No. 26222, Type: LWG-0550-000-202	プッシュロッドとロッドの端部を有するトランスデューサ
Art.No. 26224, Type: LWG-0600-000-201	プッシュロッドとロッドの端部を有するトランスデューサ
Art.No. 26230, Type: LWG-0750-000-201	プッシュロッドとロッドの端部を有するトランスデューサ
Art.No. 26150, Type: LWX-0050-001	トランスデューサ
Art.No. 26151, Type: LWX-0075-001	トランスデューサ
Art.No. 26152, Type: LWX-0100-001	トランスデューサ
Art.No. 26154, Type: LWX-0150-001	トランスデューサ
Art.No. 26155, Type: LWX-0175-001	トランスデューサ




商品名	説明
Art.No. 26157, Type: LWX-0225-001	トランスデューサ
Art.No. 26158, Type: LWX-0250-001	トランスデューサ
Art.No. 26160, Type: LWX-0300-001	トランスデューサ
Art.No. 26162, Type: LWX-0360-001	トランスデューサ
Art.No. 26166, Type: LWX-0450-001	トランスデューサ
Art.No. 26168, Type: LWX-0500-001	トランスデューサ
Art.No. 26172, Type: LWX-0600-001	トランスデューサ
Art.No. 26178, Type: LWX-0750-001	トランスデューサ
Art.No. 26250, Type: LWX-0050-001-201	トランスデューサ
Art.No. 26251, Type: LWX-0075-001-201	トランスデューサ
Art.No. 26252, Type: LWX-0100-001-201	トランスデューサ
Art.No. 26254, Type: LWX-0150-001-201	トランスデューサ
Art.No. 26255, Type: LWX-0175-001-201	トランスデューサ
Art.No. 26257, Type: LWX-0225-001-201	トランスデューサ
Art.No. 26258, Type: LWX-0250-001-201	トランスデューサ
Art.No. 26260, Type: LWX-0300-001-201	トランスデューサ
400026262 / LWX-0360-001-201	トランスデューサ
Art.No. 26266, Type: LWX-0450-001-201	トランスデューサ
Art.No. 26268, Type: LWX-0500-001-201	トランスデューサ
Art.No. 26272, Type: LWX-0600-001-201	変位センサー
Art.No. 26278, Type: LWX-0750-001-201	トランスデューサ
Art.No. 26180, Type: LWX-0050-002	トランスデューサ
Art.No. 26181, Type: LWX-0075-002	トランスデューサ
Art.No. 26182, Type: LWX-0100-002	トランスデューサ
Art.No. 26183, Type: LWX-0150-002	トランスデューサ
P/N: 400026184 Type: LWX-0175-002	トランスデューサ
Art.No. 26185, Type: LWX-0225-002	トランスデューサ
Art.No. 26186, Type: LWX0 250-002	トランスデューサ
Art.No. 26187, Type: LWX-0300-002	トランスデューサ
Art.No. 26188, Type: LWX-0360-002	トランスデューサ
Art.No. 261689, Type: LWX-0450-002	トランスデューサ
Art.No. 26192, Type: LWX-0500-002	トランスデューサ
Art.No. 26193, Type: LWX-0600-002	トランスデューサ
Art.No. 26194, Type: LWX-0750-002	トランスデューサ




商品名	説明
Art.No. 26280, Type: LWX-0050-002-201	トランスデューサ
Art.No. 26281, Type: LWX-0075-002-201	トランスデューサ
Art.No. 26282, Type: LWX-0100-002-201	トランスデューサ
Art.No. 26283, Type: LWX-0150-002-201	トランスデューサ
Art.No. 26284, Type: LWX-0175-002-201	トランスデューサ
Art.No. 26285, Type: LWX-0225-002-201	トランスデューサ
Art.No. 26286, Type: LWX0 250-002-201	トランスデューサ
Art.No. 26287, Type: LWX-0300-002-201	トランスデューサ
Art.No. 26288, Type: LWX-0360-002-201	トランスデューサ
Art.No. 262689, Type: LWX-0450-002-201	トランスデューサ
Art.No. 26292, Type: LWX-0500-002-201	トランスデューサ
Art.No. 26293, Type: LWX-0600-002-201	トランスデューサ
Art.No. 26294, Type: LWX-0750-002-201	トランスデューサ
400026302 / LWX-0050-003-101	トランスデューサ
Art.No. 26303, Type: LWX-0075-003-101	トランスデューサ
Art.No. 26304, Type: LWX-0100-003-101	トランスデューサ
P/N: 400026306, Type: LWX-0150-003-101	トランスデューサ
Art.No. 26307, Type: LWX-0175-003-101	トランスデューサ
Art.No. 26309, Type: LWX-0225-003-101	トランスデューサ
Art.No. 26310, Type: LWX-0250-003-101	トランスデューサ
Art.No. 26312, Type: LWX-0300-003-101	トランスデューサ
Art.No. 26314, Type: LWX-0360-003-101	トランスデューサ
Art.No. 26318, Type: LWX-0450-003-101	トランスデューサ
Art.No. 26320, Type: LWX-0500-003-101	トランスデューサ
Art.No. 26324, Type: LWX-0600-003-101	トランスデューサ



商品名	説明
Art.No. 26330, Type: LWX-0750-003-101	トランスデューサ
Art.No. 26402, Type: LWX-0050-003-201	トランスデューサ
Art.No. 26403, Type: LWX-0075-003-201	トランスデューサ
Art.No. 26404, Type: LWX-0100-003-201	トランスデューサ
Art.No. 26406, Type: LWX-0150-003-201	トランスデューサ
Art.No. 26407, Type: LWX-0175-003-201	トランスデューサ
Art.No. 26409, Type: LWX-0225-003-201	トランスデューサ
Art.No. 26410, Type: LWX-0250-003-201	トランスデューサ
Art.No. 26412, Type: LWX-0300-003-201	トランスデューサ
Art.No. 26414, Type: LWX-0360-003-201	トランスデューサ
Art.No. 26418, Type: LWX-0450-003-201	トランスデューサ
Art.No. 26420, Type: LWX-0500-003-201	トランスデューサ
Art.No. 26424, Type: LWX-0600-003-201	トランスデューサ
Art.No. 26430, Type: LWX-0750-003-201	トランスデューサ
Art.No. 26502, Type: LWX-0050-004-101	トランスデューサ
Art.No. 26503, Type: LWX-0075-004-101	トランスデューサ
Art.No. 26504, Type: LWX-0100-004-101	トランスデューサ
P/N: 400026506, Type: LWX-0150-004-101	変位トランスデューサ
Art.No. 26507, Type: LWX-0175-004-101	トランスデューサ
Art.No. 26510, Type: LWX0 250-004-101	トランスデューサ
P/N: 400026512, Type: LWX-0300-004-101	トランスデューサ
Art.No. 26514, Type: LWX-0360-004-101	トランスデューサ
Art.No. 26518, Type: LWX-0450-004-101	トランスデューサ
Art.No. 26520, Type: LWX-0500-004-101	トランスデューサ
Art.No. 400026524, Type: LWX-0600-004-101	変位センサー



商品名	説明
400026530 / LWX-0750-004-101	トランスデューサ
Art.No. 26602, Type: LWX-0050-004-201	トランスデューサ
Art.No. 26603, Type: LWX-0075-004-201	トランスデューサ
Art.No. 26604, Type: LWX-0100-004-201	トランスデューサ
400026606, LWX-0150-004-201	トランスデューサ
Art.No. 26607, Type: LWX-0175-004-201	トランスデューサ
Art.No. 26609, Type: LWX-0225-004-201	トランスデューサ
Art.No. 26610, Type: LWX0 250-004-201	トランスデューサ
Art.No. 26612, Type: LWX-0300-004-201	トランスデューサ
400026614 / LWX-0360-004-201	トランスデューサ
Art.No. 26618, Type: LWX-0450-004-201	トランスデューサ
Art.No. 26620, Type: LWX-0500-004-201	トランスデューサ
Art.No. 26624, Type: LWX-0600-004-201	トランスデューサ
Art.No. 26630, Type: LWX-0750-004-201	トランスデューサ
Art.No. 24303, Type: LWH-0075	プッシュロッドとトランスデューサー
Art.No. 24305, Type: LWH-0130	プッシュロッドとトランスデューサー
Art.No. 24306, Type: LWH-0150	プッシュロッドとトランスデューサー
p/n: 400024507, Type: LWH-0175	変位センサー,
Art.No. 24308, Type: LWH-0200	変位トランスデューサ (プッシュロッド付き)
Art.No. 24309, Type: LWH-0225	プッシュロッドとトランスデューサー
400024311 / LWH-0275	プッシュロッドとトランスデューサー
Art.No. 24312, Type: LWH-0300	プッシュロッドとトランスデューサー
Art.No. 24313, Type: LWH-0325	プッシュロッドとトランスデューサー
Art.No. 24315, Type: LWH-0375	プッシュロッドとトランスデューサー
Art.No. 24318, Type: LWH-0450	プッシュロッドとトランスデューサー
Art.No. 24322, Type: LWH-0550	プッシュロッドとトランスデューサー
Art.No. 24324, Type: LWH-0600	プッシュロッドとトランスデューサー
Art.No. 24330, Type: LWH-0750	プッシュロッド付き変位センサー
Art.No. 24336, Type: LWH-0900	プッシュロッドとトランスデューサー
Art.No. 25304, Type: TLH-0100	プッシュロッドなしのトランスデューサー
Art.No. 25305, Type: TLH-0130	プッシュロッドなしのトランスデューサー
Art.No. 25312, Type: TLH-0300	プッシュロッドなしの変位センサー
Art.No. 25314, Type: TLH-0360	プッシュロッドなしのトランスデューサー
Art.No. 25318, Type: TLH-0450	プッシュロッドなしのトランスデューサー
Art.No. 25320, Type: TLH-0500	プッシュロッドなしのトランスデューサー
Art.No. 25324, Type: TLH-0600	プッシュロッドなしのトランスデューサー



商品名	説明
Art.No. 25330, Type: TLH-0750	プッシュロッドなしのトランスデューサー
Art.No. 25336, Type: TLH-0900	プッシュロッドなしのトランスデューサー
Art.No. 25350, Type: TLH-1250	プッシュロッドなしのトランスデューサー
Art.No. 25360, Type: TLH-1500	プッシュロッドなしのトランスデューサー
Art.No. 25370, Type: TLH-1750	プッシュロッドなしのトランスデューサー
P/N: 400025380 Type: TLH-2000	プッシュロッドなしのトランスデューサー
Art.No. 25381, Type: TLH-2250	プッシュロッドなしのトランスデューサー
Art.No. 25383, Type: TLH-2500	プッシュロッドなしのトランスデューサー
Art.No. 25384, Type: TLH-2750	プッシュロッドなしのトランスデューサー
Art.No. 25385, Type: TLH-3000	プッシュロッドなしのトランスデューサー
Art.No. 43502, Type: LFP-0050-001-001-001	電位差式位置センサー
Art.No. 43504, Type: LFP-0100-001-001-001	Potentiometrische Wegsensoren
Art.No. 43506, Type: LFP-0150-001-001-001	Potentiometrische Wegsensoren
Art.No. 43508, Type: LFP-0200-001-001-001	Potentiometrische Wegsensoren
Art.No. 43510, Type: LFP-0250-001-001-001	Potentiometrische Wegsensoren
Art.No. 43512, Type: LFP-0300-001-001-001	Potentiometrische Wegsensoren
Art.No. 43514, Type: LFP-0350-001-001-001	Potentiometrische Wegsensoren
Art.No. 43516, Type: LFP-0400-001-001-001	Potentiometrische Wegsensoren
Art.No. 43518, Type: LFP-0450-001-001-001	Potentiometrische Wegsensoren
Art.No. 43520, Type: LFP-0500-001-001-001	Potentiometrische Wegsensoren
Art.No. 2187, Type: PTN-025	並進抵抗素子
Art.No. 2188, Type: PTN-050	並進抵抗素子
Art.No. 2189, Type: PTN-075	並進抵抗素子
Art.No. 2190, Type: PTN-100	並進抵抗素子
Art.No. 2191, Type: PTN-150	並進抵抗素子
Art.No. 2192, Type: PTN-200	並進抵抗素子
Art.No. 2193, Type: PTN-250	並進抵抗素子
Art.No. 22301, Type: PTX 0010	並進抵抗素子
Art.No. 22302, Type: PTX 0025	並進抵抗素子
p/n: 22303, Type: PTX 0050	
Art.No. 22304, Type: PTX 0075	並進抵抗素子
Art.No. 22305, Type: PTX 0100	並進抵抗素子
Art.No. 22307, Type: PTX 0150	並進抵抗素子
Art.No. 22309, Type: PTX 0200	並進抵抗素子
Art.No. 22311, Type: PTX 0250	並進抵抗素子
Art.No. 22313, Type: PTX 0300	並進抵抗素子
Art.No. 70108, Type: S-114	グラインダーセット




商品名	説明
Art.No. 2161, Type: S-115	グラインダーセット
Art.No. 21110, Type: S-170	グラインダーセット
Art.No. 5617, Type: EEM-33-64	シリーズの接続技術M8x1
Art.No. 5619, Type: EEM-33-66	シリーズの接続技術M8x1
Art.No. 5643, Type: EEM-33-68	シリーズの接続技術M8x1
P/N: 400005618, Type: EEM-33-65	シリーズ用 M8x1 接続テクノロジー
P/N: 400005620 Type: EEM-33-67	
P/N: 400005644, Type: EEM-33-69	シリーズ用 M8x1 接続テクノロジー
Art.No. 5600, Type: EEM-33-32	シリーズ用M12x1接続技術
Art.No. 5609, Type: EEM-33-62	シリーズ用M12x1接続技術
Art.No. 5650, Type: EEM-33-97	シリーズ用M12x1接続技術
Art.No. 5601, Type: EEM-33-33	シリーズ用M12x1接続技術
Art.No. 5610, Type: EEM-33-63	シリーズ用 M12x1 接続テクノロジー
400005696 / EEM-33-99	シリーズ用M12x1接続テクノロジー
EEM-33-71, 400005612	
EEM 33-70	
Art.No. 5613, Type: EEM-33-72	シリーズの接続技術M16x0.75 (IEC130-9)
Art.No. 58100, Type: Z-G60	ボールカップリング、ボールジョイントヘッド、トレーサーローラー
Art.No. 56014, Type: Z-G01	ボールジョイントヘッドデザイン
400058001 / Z301-M6/M6	ボールカップリングバージョン
Art.No. 5679, Type: Z301-M6/M4	ボールカップリングバージョン
Art.No. 58002, Type: Z-301-M5/M5	ボールカップリング
400070301	テンションクリップ、プッシュロッド、プッシュピン
Art.No. 56027, Type: Z-TLM-B01	クランプ、プッシュロッド、プッシュピン
Art.No. 56028, Type: Z-TLM-B02	クランプ、プッシュロッド、プッシュピン
Type: RSC-3101-636-732-902	角度センサー
Type: RSC-3202-711-233-521	角度センサー
Type: RSC-6601-635-924-001 OEM	角度センサー
p/n: 400005660; Type: Z-RFC-P01	シリーズのための位置センサ
Art.No. 5661, Type: Z-RFC-P02	シリーズのための位置センサ
Art.No. 5658, Type: Z-RFC-P03	シリーズのための位置センサ
P/N: 005659 Type: Z-RFC-P04	長作動距離
Art.No. 56069, Type: Z-RFC-P07	シリーズのための位置センサ
Art.No. 56070, Type: Z-RFC-P08	シリーズのための位置センサ
Art.No. 104203, Type: Z-RFC-P16	シリーズのための位置センサ
Art.No. 104205, Type: Z-RFC-P17	シリーズのための位置センサ
Art.No. 56074, Type: Z-RFC-P23	シリーズのための位置センサ
400056086 / Z-RFC-P30	シリーズ用ポジションセンサー
Art.No. 56206, Type: Z-RFC-S01	シリーズのための位置センサ
Art.No. 56207, Type: Z-RFC-S02	シリーズのための位置センサ
Art.No. 56208, Type: Z-RFC-S03	シリーズのための位置センサ
Art.No. 56135, Type: EEM-33-35	シリーズ用M12x1接続技術
Art.No. 56136, Type: EEM-33-36	シリーズ用M12x1接続技術
Art.No. 56137, Type: EEM-33-37	シリーズ用M12x1接続技術
Art.No. 56138, Type: EEM-33-38	シリーズ用M12x1接続技術



商品名	説明
Art.No. 56139, Type: EEM-33-39	シリーズ用M12x1接続技術
Art.No. 56140, Type: EEM-33-40	シリーズ用M12x1接続技術
Art.No. 56501, Type: Z-IPX-M01	アクセサリセンサーは、シリーズの取付け
Art.No. 56502, Type: Z-IPX-M11	アクセサリセンサーは、シリーズの取付け
Art.No. 56504, Type: Z-IPX-M31	アクセサリセンサーは、シリーズの取付け
Art.No. 104278, Type: Z-RFX-M01	アクセサリセンサーは、シリーズの取付け
Art.No. 5666, Type: EEM 33-34	アクセサリコネクタキット
Art.No. 2203, Type: P-2201-A502	低トルクポテンシオメータ
P/N: 400002224, Type: P-2220-S0035	低トルクポテンシオメータ
400003201 / P-2501-A102	標準ポテンシオメータ
Art.No. 3202, Type: P-2501-A202	標準ポテンシオメータ
Art.No. 3203, Type: P-2501-A502	標準ポテンシオメータ
Art.No. 6201, Type: P-4501- A102	標準ポテンシオメータ、複数（積層）
Art.No. 6202, Type: P-4501- A202	標準ポテンシオメータ、複数（積層）
Art.No. 6208, Type: P-4501- A502.05	標準ポテンシオメータ、複数（積層）
P/N: 006209 Type: P-4502-A502	
Art.No. 8201, Type: P-6501-A102	標準ポテンシオメータ、複数（積層）
Art.No. 8202, Type: P-6501-A202	標準ポテンシオメータ、複数（積層）
Art.No. 8203, Type: P-6501-A502	標準ポテンシオメータ、複数（積層）
Art.No. 8224, Type: P-6501-S0049	標準ポテンシオメータ、複数（積層）
P/N: 400008221 Type: P-6501-G252	標準ポテンシオメータ、複数（ステープル）
Art.No. 8225, Type: P-6501-R252	標準ポテンシオメータ、複数（積層）
Art.No. 10001, Type: IP-6501-A502	産業ポテンシオメータ
Art.No. 10002, Type: IP-6501-A502.05	産業ポテンシオメータ
Art.No. 10040, Type: PE-6501-S0055	産業ポテンシオメータ
Art.No. 1041, Type: PE-6501-S0056	産業ポテンシオメータ
Art.No. 10061, Type: IPS-6501-A502	産業ポテンシオメータ
P/N: 400010066 Type: IPS-6501-G252	ロータリーセンサー工業用グレードポテンシオメータ
Art.No. 10065, Type: IPS-6502-A502	産業用ポテンシオメータ
Art.No. 11021, Type: AW-360-ZE-10	産業ポテンシオメータ
Art.No. 11022, Type: AW-360-ZE-11	産業ポテンシオメータ
P/N: 400011061 Type: AWS-360-ZE-10	丸型ポテンシオメータ360°
Art.No. 9121, Type: IGP-03-P-6501-A502	トランスミッションポテンシオメータ
Art.No. 9122, Type: IGP-05-P-6501-A502	トランスミッションポテンシオメータ
P/N: 400009123 Type: IGP-10-P-6501-A502	ギヤードポテンシオメータ
Art.No. 9111, Type: GP-03-P-6501-A502	トランスミッションポテンシオメータ
P/N: 009112 Type: GP-05-P-6501-A502	




商品名	説明
Art.No. 9113, Type: GP-10-P-6501-A502	トランスミッションポテンショメータ
Art.No. 18402, Type: SP-1601-105-001-001	センサ、ポテンショメータ
Art.No. 38001, Type: SPK-2501-A5033	センサ、ポテンショメータ
Art.No. 38002, Type: SPK-2501-A1812	センサ、ポテンショメータ
SP2801 308 000 001	角度トランスデューサ 308° 5kOhm
Art.No. 019522, Type: SP-2801-100-002-001	センサ、ポテンショメータ
P/N: 19540, Type: SP-2821-308-000-001	角度ポテンショメータ位置センサ
Art.No. 19521, Type: SP-2831-308-000-001	センサ、ポテンショメータ
Art.No. 19527, Type: SP-2831-100-002-001	センサ、ポテンショメータ
P/N: 019542 Type: SP-2841-100-002-001	
Art.No. 19561, Type: SP-2841-100-002-906	センサ、ポテンショメータ
400019564 / SP-2841-345-065-001	センサー電位差計
P/N: 400019565, Type: SP-2841-100-067-006	センサ、ポテンショメータ
400019543 / SP-2841-100-002-003	センサ、ポテンショメータ
Art.No. 18400, Type: SP-4001-101-003-003	センサー・ポテンショメータ、自動車用バージョン
Art.No. 18501, Type: SP-5001-104-002-002	センサ・ポテンショメータ（自動車版）
Art.No. 18504, Type: SP-5001-114-005-001	センサ・ポテンショメータ（自動車版）
Art.No. 65111, Type: PRS 25 A 502	ロータリーの抵抗素子
Art.No. 65114, Type: PRS 45 A 502	ロータリーの抵抗素子
Art.No. 65115, Type: PRS 65 A 502	ロータリーの抵抗素子
Art.No. 70137, Type: S-094	回転抵抗素子用グラインダーセット
Art.No. 70138, Type: S-098	回転抵抗素子用グラインダーセット
Art.No. 70139, Type: S-152	回転抵抗素子用グラインダーセット
Art.No. 5614, Type: EEM-33-76	シリーズの接続技術M16x0.75 (IEC130-9)
Art.No. 5615, Type: EEM-33-77	シリーズの接続技術M16x0.75 (IEC130-9)
Art.No. 5621, Type: EEM-33-78	シリーズの接続技術M16x0.75 (IEC130-9)
Art.No. 5622, Type: EEM-33-79	シリーズの接続技術M16x0.75 (IEC130-9)
p/n: 5623, Type: EEM-33-80	カプラー
Art.No. 5687, Type: Z-103-G03	シリーズのウェーブとフォークのカップリング
Art.No. 5690, Type: Z-104-G06	シリーズのウェーブとフォークのカップリング
Art.No. 400103910, Type: Z-106-G-6	シャフトカップリング
Art.No. 103912, Type: Z-106-G-6.35	シリーズのウェーブとフォークのカップリング
Art.No. 103913, Type: Z-106-G-10	シリーズのウェーブとフォークのカップリング
Art.No. 5692, Type: Z-110-G10	シリーズのウェーブとフォークのカップリング




商品名	説明
Art.No. 59013, Type: ZK1-500	シリーズのウェーブとフォークのカップリング
Art.No. 54220, Type: MUP-080-111	信号処理、送信
400054221 / MUP-080-113	変換器
400054202 / MUP-400-11	信号処理、送信機
400054101 / MUW-200-0	ポテンショメータ用トランスデューサ
Art.No. 54102, Type: MUW-200-1	ポテンショメータ用トランスデューサ
Art.No. 54103, Type: MUW-200-4	ポテンショメータ用トランスデューサ
Art.No. 54151, Type: MUW-250-0	ポテンショメータ用トランスデューサ
P/N: 400054152 Type: MUW-250-1	ポテンショメータ用トランスデューサ
Art.No. 54001, Type: MUP-100-0	ポテンショメータ用トランスデューサ
MUP-100-1 / 400054002	
p/n: 400054010, Type: MUP-110-0	ポテンショメータ用測定値トランスデューサ
400054011 / MUP-110-1	ポテンショメータトランスデューサ
Art.No. 54014, Type: MUP-110-4	ポテンショメータ用の変換器の測定
Art.No. 54051, Type: MUP-150-5	ポテンショメータ用トランスデューサ
Art.No. 54052, Type: MUP-150-6	ポテンショメータ用トランスデューサ
Art.No. 54060, Type: MUP-160-0	ポテンショメータ用トランスデューサ
400054061 / MUP-160-1	ポテンショメータ用トランスデューサ
Art.No. 54064, Type: MUP-160-4	ポテンショメータ用トランスデューサ
Art.No. 54171, Type: MUK-350-0	ポテンショメータ用トランスデューサ
Art.No. 54172, Type: MUK-350-1	ポテンショメータ用トランスデューサ
P/N: 400054173, Type: MUK-350-4	ポテンショメータ用トランスデューサ
Art.No. 400054174, Type: MUK-350-6	ポテンショメータ用トランスデューサ
Art.No. 025304, Type: TLH-0100	ブッシュロッドなしの変位センサー
TH1-0250-102-423-101	測定変換器信号変換
P/N: 025385 Type: TLH-3000	トランスデューサ
P/N: 400005655 Type: Z-TLM-P05	POSITIONSGEBER
P/N: 026168 Type: LWX-0500-001	ポジショントランスデューサ
4000370HX	
P/N: 025330 Type: TLH-0750	
P/N: 400024520, Type: LWH-0500	トランスデューサ
P/N: 010001 Type: IP-6501-A502	
P/N: 400024509, Type: LWH-0225	変位センサー
RSM 2832-010-111-206	
TRS 75 A 502	位置変換器ポテンショメータ
P/N: 025305 Type: TLH-0130	ポジショントランスデューサ
RSC-2801-606-112-201	角度センサー
P/N: 400037109, Type: TX2-0250-716-002-101	変位トランスデューサ
400054003	変換器
P/N: 024306 Type: LWH-0150	位置トランスデューサ
400054051 / MUP-150-5	
P/N: 400019544, Type: SP-2841-130-050-003	センサー電位差計




商品名	説明
RSC-2831-612-211-201	ANGLE SENSOR非接触式
P/N: 054171 Type: MUK-350-0	
TRS-0050 (alt number TRS 50 A 502)	ポジションエンコーダー
P/N: 024312 Type: LWH-0300	
400005679 / Z301-M6/M4	ボールカップリング、ボールジョイントヘッド、タッチローラー
P/N: 023262 Type: TR-0050	分圧器
Nr: 054051 Type: MUP-150-5	シグナルコンディショナー
P/N: 024304 Type: LWH-0100	変位センサー
P/N: 023267 Type: TR-0050-.05	
P/N: 023277 Type: TRS-0050-.05	
P/N: 026114 Type: LWG-0360	プッシュロッドとロッドエンドを備えた変位センサ
P/N: 005634 Type: EEM-33-89	コネクタ
LWH360 #024314	ポジショントランスデューサ
TP1-0500-101-411-101	トランスデューサ
P/N: 025318 Type: TLH-0450	プッシュロッドなしのトランスデューサー
deleted product	電位差計
TP1 100 101 411 101	非接触リニアローラー
P/N: 025304 Type: TLH-0100	トランスデューサ
Type: MUP-110-4	
RFC-4801-636-111-501	
P/N: 005611 Type: EEM-33-70	
P/N: 400024318 Type: LWH-0450	ENCODED
P/N: 400025305 Type: TLH-0130	リニアポテンシオメータ位置センサ
RFC-4801-636-121-501	
P/N: 400058100 Type: Z-G60	ボールジョイントヘッド、内部スレッド M6
Typ: TLH 360	
Type: LWH-0100 P/N:024304	
400024536 / LWH-0900	ポジショントランスデューサ
P/N: 400001041 Type: IPE-6501-S0056	Potentiometer
TH1-0800-102-423-101	NOVOSTRICTIVE、マグネトストリクティブウェイガウフナー
400023235 / TS-0100	変位センサー
400005612 / EEM-33-71	接続技術
P/N: 400024504 Type: LWH-0100	変位トランスデューサ
400026124 / LWG-0600	トランスデューサ
400024524 / LWH-0600	ポジショントランスデューサ
400024326 / LWH-0650	
P/N: 400019521, Type: SP-2831-308-000-001	センサー-ポテンシオメーター
400024516 / LWH-0400	ポジショントランスデューサ
400024316 / LWH-0400	リニアセンサー
P/N: 025383 Type: TLH-2500	
P/N: 025309 Type: TLH-0225	ENCODED
P/N: 400006201 Type: P-4501-A102	ロータリーセンサー




商品名	説明
LS1-0025-002-421-101	NOVOPAD ポジショントランスデューサ、リターンズプリング付き、最大100mm、非接触式
P/N: RFC-4801-636-111-201	
TP1-0250-101-423-205	
P/N: 400024514, Type: LWH-0360	トランスデューサ
P/N: 400019527 Type: SP-2831-100-002-001	
TP1-0600-101-212-101	
TP1-0300-101-212-101	
TP1-0100-101-212-101	
P/N: 005698 Type: Z-TH1-P19	
P/N: 400003201 Type: P-2501-A102	
P4504-S0060-2K / 54000019	ポテンシオメータ
IP-6501-A502.025	
400005611 / EEM 33-70	接続技術
PTP-0200-444-901-301	
PTP-0075-444-901-301	
400023263 / TR-0075	リターンズプリング電位差測定機能付きポジショントランスデューサ
400025350 / TLH-1250	ポジショントランスデューサ
P/N: 023206 Type: T-0150	
P/N: 400024336 Type: LWH-0900	
P/N: 026102 Type: LWG-0050	
400026104 / LWG-0100	ウェガウフネーマー
Z-TLM-P05	
P/N: 024302 Type: LWH-0050	電位差式リニアルーラー
P/N: 400025324, Type: TLH-0600	エンコーダ
4000350FT / TP1-0300-101-411-102	
54000005	電位差計
P/N: 019564 Type: SP-2841-345-065-001	
MUP 400-11 / 054202	信号処理、送信
024314, LWH-0360	トランスデューサ
P/N: 0550 Type: LWH-0550	
TP1-1000-101-411-205	ENCODED
P/N: 026160 Type: LWX-0300-001	変換器
P/N: 026162 Type: LWX-0360-001	
P/N: 026168 Type: LWX-0500-005	
P/N: 400026312 Type: LWX-0300-003-101	トランスデューサ
P/N: 400026314, Type: LWX-0360-003-101	位置トランスデューサ
P/N: 400026320 Type: LWX-0500-003-101	トランスデューサ
P/N: 400005601, Type: EEM 33-33	コネクタ
P/N: 400005610 Type: EEM 33-63	
P/N: 400005634 Type: EEM 33-89	




商品名	説明
P/N: 40003500K Type: TP1-0200-101-423-102	VZTYP ENCODED
P/N: 400005651 Type: Z-TLM-P01	POSゲベル
P/N: 400005630 Type: EEM 33-87	W-用量
p/n: 400005697 type: Z-TH1-P18	リング
P/N: 400008201 Type: P-6501-A102	
P/N: 002003 Type: P-2201-A502	
TP1-0650-101-423-101	
P/N: 024310 Type: LWH-0250	ポテンショメータ
P/N: 400024522, Type: LWH-0550	プッシュロッド付き変位センサー
P/N: 400026112, Type: LWG-0300	変位トランスデューサ
P/N: 400025318, Type: TLH-0450	ウェーガウフナー
RFC-4801-609-111-201	ロータリーセンサー
P/N: 400026172 Type: LWX-0600-001	変換器
54000019 (P4504-S0060)	ポテンショメーター
P/N: 400008224 Type: P-6501-S0049	センサー
TH1-0500-102-423-102	トランスデューサ
P/N: 400005698 Type: Z-TH1 P19	リング
EEM33-90	ストレートコネクタ付きケーブル、5メートル
P6512a502	
P/N: 400025350 Type: TLH-1250	
400006209 / P-4502-A502	RUNDPOTENTIOMETER
TH1-0800-102-423-102	変位センサー
P/N: 400010001 Type: IP-6501-A502	ポテンショメーター
400019521 / SP-2831-308-000-001	SENSOR-ポテンショメータ
RFD-4001-636-221-401	角度センサー
400019542	
EEM33-91	ケーブル
4000350BN	トランスデューサ
P/N: 400023234 Type: TS-0075	
400019560 / SP-2846-345-065-101	センサーポテンションメーター
P/N: 400024309 Type: LWH-0225	ポテンショメータライン
TEX-0050-415-002-101	
P/N: 400026283 Type: LWX-0150-002-201	位置トランスデューサ
THL-0225	
P/N: 400023232, Type: TS-0025	位置トランスデューサ、電位差
RFC-4853-636-121-202	
400005659 / Z-RFC-P04	位置センサー
P/N: 400054052 Type: MUP150-6	
RFC-4853-611-121-202	ストアSENSOR
TH1-0775-102-423-102	
P/N: 400019561 Type: SP-2841-100-002-906 oem	



商品名	説明
TP1-0900-101-211-102	位置エンコーダ
P/N: 400006102, Type: LWG-0050	P/N: 026102 タイプ: LWG-0050
TP1-0850-101-411-102	
TP1-0250-101-411-102	
RFC 4801-609-112-201	センサー
P/N: 400009121 Type: IGP-03-P-6501-A502	電位差計
RFC-4853-609-112-202	非接触センサー
400009121	ギヤードポテンショメータ
P/N: 400023271 Type: TRS-0025	
400024512 / LWH-0300	プッシュロッド付き変位センサー
P/N: 400005613 Type: EEM-33-72	コネクタ
P/N: 400054172 Type: MUK-350-1	
TEX 150-415-002-101	位置変換器
TP1-2000-101-411-101	磁歪ポジションルーラー
TP1-2000-101-411-205	磁歪ポジションルーラー
P/N: 400005627 Type: EEM-33-84	
402610515	アダプタ
TH1-0450-102-423-102	ラインの位置エンコーダ
TH1-3250-102-423-102	ノボストリクティブ、マグネストリクティブ
RSM-2832-006-121-501	センサー
TP1-0125-101-215-205	トランスデューサ
P/N: 400023260, Type: TR-0010	ポジショントランスデューサ
P/N: 400023269 Type: TR-0100-.05	トランスデューサ
RSC-2831-636-121-201	センサー
TEX-0200-415-002-202	
I 50	リニア位置センサ
RSC-2801-620-111-206	角度センサー
P/N: 400053102, Type: FTI-10-2.67-4-K1	非接触、誘導位置トランスデューサ
P/N: 400023261 Type: TR-0025	変位トランスデューサ
P/N: 400054151 Type: MUW-250-0	コンバータ
400005661 / Z-RFC-P02	ポジションマーカー
P/N: 400024508, Type: LWH-0200	プッシュロッドとの位置トランスデューサ
TX2-0050-904-002-403-4	
TP1-1500-101-411-102	トランスデューサ
RFC-4801-606-111-202	センサー
TP1-0600-101-423-205	リニア定規
P/N: 400010018 Type: IP-6501-4007	電位差計
TH1-0500-102-423-101	トランスデューサ
TH1-0150-102-423-101	トランスデューサ
TEX-0025-421-002-101	位置トランスデューサ
P/N: 400002227 Type: P-2201-S0076	ポテンショメータ
P/N: 400009112, Type: GP-05-P-6501-A502	ギアポテンショメータ




商品名	説明
P/N: 400024512, Type: LWH-300	センサー
TP1-1000-101-411-101	トランスデューサ
P/N: 400003203 Type: P-2501-A502	電位差計
P/N: 400008202 Type: P-6501-A202	電位差計
RSC-2831-610-111-201	角度センサ
TP1-0050-101-411-101	
400054172 / MUK-350-1	POSITION AMPLIFIER
P/N: 400019540 Type: SP-2821-308-000-001	センサーポテンシオメータ
TP1-0600-101-423-101	変位トランスデューサ
400024515 / LWH-0375	位置変換器
TP1-1600-101-423-101	磁歪ポジション表
P/N: 400010004 Type: IP-6501-G252	ポテンシオメータ
RFC 4801-605-111-201	角度センサ
P/N: 400056126 Type: EEM-33-26	コネクタ
P-6501-A502 (400008203)	RUNDPOTENTIOMETER
Type: IP-6501-A502	
TEX-0050-411-002-101	変位トランスデューサ、電位差
P/N: 400025330 Type: TLH-0750	トランスデューサ
TE1-0025-101-411-202	電位差変位センサ
TE1-0050-101-411-202	
P/N: 400026114 Type: LWG-0360	
400023273 / TRS-0075	トランスデューサ
400023202 Typ T-0025	トランスデューサ
RSC-2832-636-111-202	角度センサー
LS1-0200-001-421-101	位置変換器
P/N: 400025344, Type: TLH 1100	
TEX-0025-418-002-101	300mmまでの変位トランスデューサ
TEX-050-615-002-101 oem	線形電位差計
400023264 / TR-0100	ポジショントランスデューサ
P/N: 400025309 Type: TLH-0225	プッシュロッド無し位置トランスデューサ
TH1 0650 102 411 102	
TH1 1300 102 411 102	
RSM-2841-016-111-202	角度センサー
TH1-0150-102-423-102	位置センサー
SPK-2501-A5033	センサー電位差計
TR-0025 (400023261)	ウェブタスター
400024314 / LWH-0360	ポジショントランスデューサ
P/N: 400026130 Type: LWG-0750	変位センサー
Art.Nr. 402517875	カッター
P/N: 400024324 Type: LWH-0600	線形電位差計
P/N: 400025336, Type: TLH-0900	ポジショントランスデューサ
P/N: 400025320 Type: TLH-0500	リニアポテンシオメータ
P/N: 400025314, Type: TLH-0360	位置トランスデューサ
400026120 / LWG-0500	トランスデューサ



商品名	説明
P/N: 400010065 Type: IPS-6502-A502	
P/N: 400005690 Type: Z-104-G-06	
P/N: 400037102 Type: TX2-0050-716-002-101	電位差計
TP1-0600-101-411-101	
P/N: 400019541 Type: SP-2841-308-000-001	センサーポテンシオメータ
P/N: 400024505, Type: LWH-0130	ポジショントランスデューサ
P/N: 400024303 Type: LWH-0075	変位トランスデューサ
P/N: 400025306 Type: TLH-0150	変位変換器
RSC-2800-610-112-201	角度センサー
P/N: 400025304, Type: TLH-0100	ザ・ルーラー
LS1-0025-001-423-101	コネクタ付きアナログインターフェース
RSC-2841-636-111-202	ロータリーセンサー
RFC-4853-636-321-252	ロータリーセンサーのタッチレス技術
P/N: 400019542 Type: SP-2841-100-002-001	センサーポテンシオメータ
TH1-0350-102-423-102	
RSM-2841-002-211-202	センサー
TEX 0025-415-002-101	変位トランスデューサ、電位差測定
400023233 / TS-0050	変位トランスデューサ
400025330 / TLH-0750	ENCODED 商品番号：025330
RSC-2832-605-121-202	センサー
P/N: 400025307 Type: TLH-0175	センサー
400025314 / TLH-0360	センサー
400025321 / TLH-0525	センサー
P/N: 400024314 Type: LWH-0360	トラベルセンサー
RSC-2801-603-112-201	ロータリーセンサー
RSC 2831-609-121-201	角度センサー
400023274 / TRS-0100	位置変換器
TP1-0400-101-423-205	リニアルーラー
T-0075	リニアトランスデューサ
TEX-0100-413-002-202	位置センサー、ポテンシオメトリック
TE1-0025-102-411-202	
TP1-1500-101-411-205	トランスデューサー
400025311 / THL-0275	センサー
400023204 / T-0075	
400023205 / T-0100	連続プッシュロッド付き変位センサー
P/N 400026507 Type: LWX-0175-004-101	トランスデューサ
400009112 / GP-05-P-6501-A502	伝送電位差計
400010018 / IP-6501-4007	産業用電位差計
400026330 / LWX-0750-003-101	電位差変位センサ
400005634 / EEM 33-89	位置トランスデューサ
400026178 / LWX-0750-001	電位差変位センサ



商品名	説明
P/N: 400025370, Type: TLH-1750	リニア位置探触子
Typ: LWG 150, Art.Nr.: 002461	
TEX-0150-411-002-101	位置トランスデューサ
TH1 1600 102 411 205	
ML25-10K0 125MB #82445	
400003264 / P-2501-240-386-001	ロータリーセンサーマルチセクションポテンショメータ
400024318 / LWH-0450	変位トランスデューサ
p/n: 025324; Type: TLH-0600	変位トランスデューサ (プッシュロッドなし)
400025316 / TLH-0400	
RSM-2832-010-111-202	角度センサ
LS1-0025-002-411-202	センサー
RFC-4801-607-112-501	ロータリーセンサー
400056070 / Z-RFC-P08	ポジショナー
400023261 / TR-0025	連続スライディングロッド100ミリメートルトランスデューサ
RSC-2802-612-121-201	
RFD-4021-636-211-401 (400039DA4)	VZTYP 角度センサー
400011021 / AW-360-ZE-10	
4000350HC	トランスデューサ
4000350BZ	トランスデューサ
4000350C3	トランスデューサ
400026114 / LWG-0360	線形電位差計
TP1-0450-101-411-205	
RFD 4021-636-211-401	センサー
RFC-4801-606-111-201	センサー
RFC-4853-606-111-201	
TP1-0200-101-411-103	
LWH-0300	位置センサー、ポテンシオメトリック、LWHシリーズ、TLH
400106229, RFC-4853-618-121-206	角度センサー
TEX 0075-411-002-101	ポジショントランスデューサ
400054220 / MUP-080-111	変換器
RSM-2841-002-213-202	角度センサー
400019542 / SP-2841-100-002-001	角度ポテンシオメータ位置センサ
RSM-2841-003-111-206	プラグインカップリング
TEX-0100-415-002-202	ポジショントランスデューサ
400054201 / MUP-400-01	インターフェースモジュール
TRS-0050/1019993	
TP1-0100-101-423-101	トランスデューサー
TP1-0050-101-423-102	トランスデューサ
p/n: 400056059; Type: Z-TP1-S01-0450	プッシュロッド
p/n: 400024322; Type: LWH-0550	位置変換器
RSC-2831-636-111-201	回転位置センサー
MUK-350	変換器
TP1-0500-101-411-102	電位差計




商品名	説明
400005694 / Z-TP1-P07	ポジショナー
400005635 / EEM-33-90	シリーズ用接続システム M12x1
RSC-2801-714-213-201	角度センサー
TP1 1000 101 841 205	トランスデューサ、
TP1 0250 101 841 102	トランスデューサ
400053102 / FTI-10-2.67-4-K1	[パス] ボタン
P4519 S0060 F.N.R : 070971/ 0186	電位差計
TEX-0150-415-002-202	ENCODED
024309 LWH-0225	電位差センサー
RFC-4853-636-211-401	VZTYP角度センサー
P/N: 024427, Type: LWH-0175	
RFC-4801-609-321-256	
40005401x / MUP-110	
TH1-1400-102-423-101	ポジショントランスデューサ
TH1 1150 102 423 102	
Type: EEM-33-71, P/N: 400005612	TS/TRS シリーズ用接続技術 M16x0.75 (IEC130-9)
RSC 2831-610-121-201	角度センサー
TP1-1800-101-423-101	
400025340 / TLH-1000	リニアセンサー
p/n: 023202, Type: T-0025	変位トランスデューサ
400105988 / RFC-4853-636-111-501	角度センサー
LWH-0400	プッシュロッド付き変位センサー
400019532	センサーポテンショメータ
TP1-1400-101-841-102	変位トランスデューサ
400054103 / MUW-200-4	プラグタイプ
400009122 / IGP-05-P-6501-A502	
RSB-3607-636-111-FM4	
Art.No. 10018, Type: IP-6501-4007	産業用電位差計
LWG-0130, 400104722	線形電位差計
P/N: 005325 Type: F200G	変換器
400006205 / P-4501-A103	回転センサーポテンツメーター
400107045 / TRS-0025-101	
TEX-0025-428-002-302	
TP1-0900-101-411-205	磁歪位置定規
RFC-4853-636-121-501	角度センサー
TEX-0250-415-002-202	
TH1-0500-102-411-203	ポジショントランスデューサ
400024361 / LWH-0350	
4000370KB	
TE1-0025-101-422-202	
RSC2831-636-111-202	センサー角度
RSM-2821-006-111-220	マルチターンセンサー
P/N: 400005691, Type: Z-105-G-06	フォークカップリング Ø 6 mm、バックラッシュフリー
400005666 / EEM-33-34	コンタクト、シールを含むMQSプラグキット
RSX-7911-636-321-252	ロータリーセンサー




商品名	説明
RSX-7911-836-324-651	ロータリーセンサー
P/N: 400023206, Type T-0150	ショートストロークトランスデューサ
04229629600	ポテンシオメータ
400002203 / P-2201-A502	
RSC 2832-636-121-202	
RSC-2831-609-111-201	
RSC-2831-618-121-201	
RFC-4801-618 -111-206	エンコーダー
TH1-0600-102-211-101	
4000370MU / TEX-0150-415-002-101	
TP1-0800-101-A12-107	
TP1-0200-101-A12-107	
400024510 / LWH-0250	トランスデューサ
TEX-0300-415-002-101	ポジショントランスデューサ
RFC-4853-609-111-201	角度センサー
400059010 / Z-FTI-B01	取り付けクランプ
RSC 2831 736 223 201	ロータリーセンサー
RFC-4801-609-111-206	
TP1-1500-101-211-102	
TH1-1300-102-423-102	変位トランスデューサ
TEX-0150-411-002-202	トランスデューサ
RFC-4853-603-121-501	角度センサー
RSC-2801-636-111-201	角度センサー
P/N: 400005303, Type: F-205-G	ポジショントランスデューサ
TP1-0325-101-411-205	非接触ルーラー
TP1-0225-101-411-205	非接触ルーラー
P/N: 025332, Type: TLH-800	ポジショントランスデューサ
RSM-2862-016-121-501	
PN: 400012021 / Type: IPX 7901 107 120 103	角度センサー
TH1-0200-102-423-101	リニアトランスデューサ
LWG 0500	コースセンサー
LWH-0075 P/N 024303	リニアポテンシオメータ位置センサ
TEX-0075-415-002-101	ウェイセンサー
P/N: 400024307, Type: LWH 175	変位トランスデューサ
PTP-0125-311-002-001	
400002227 / P-2201-S0076	低トルクポテンシオメータ
RFC-4801-6318-111-201	ロータリーセンサ
400037306 / TX2-0150-717-002-101	最大 300 mm のトランスデューサ、マウンティングブロック付き
TP1-1000-101-423-101	変位センサー
400023262 / TR-0050	
400019520 / SP-2801-308-000-001	センサ、ポテンシオメータ
400005614 / EEM-33-76	接続性
TE1-0050-102-411-101	変位センサー
400024503 / LWH-0075	変位トランスデューサ、プッシュロッド付き



商品名	説明
TEX-0100-615-002-202	
400024507 / LWH-0175	
TP1-0250-101-423-102	トランスデューサ
TP1-1500-101-411-101	
ML6-5K0 125MB #82595	
RSM-2862-016-121-202	マルチターンセンサー
RFC-4801-636-321-551	ロータリーセンサー
RFC 4801-622-321-501	センサー
RSC 2841 636 211 202	ロータリーセンサー
TP1-0300-101-211-102	トランスデューサ
RSM-2841-003-111-202	プラグインカップリング
400037106 / TX2-0150-716-002-101	
TH1-0600-104-423-102	
RSC-2801-609-111- 201	角度センサー
4000370NZ	変位トランスデューサ
TP1-1100-101-423-101	トランスデューサ
TH1-0100-102-411-102	トランスデューサ
TP1-0400-101-423-203	トランスデューサ
RFE-3201-706-213-521	
TFD-4021-724-213-411	トランスデューサ 5 ~ 50 mm タッチレス
TFD-4021-624-211-401	トランスデューサ 5 ~ 50 mm タッチレス
MAP-4010-411-101	ディスプレイ付き多機能測定装置
RSC-2831-736-213-202	ロータリーセンサー非接触
RSC-2801-736-213-202	ロータリーセンサー非接触
RSC-2861-736-213-202	ロータリーセンサー非接触
TEX-0150-413-002-202	
LS1-0025-002-411-101	変位センサー
TH1-0300-102-423-102	トランスデューサ
TH1-0300-102-423-203	トランスデューサ
TP1-0150-101-411-101	リニアポジションセンサー
400105799 / RFC-4853-622-121-501	
TEX-0050-421-002-101	電位差計
400108613 / TM1-0075-305-811-104	VZTYP 変位センサー
400108614 / TM1-0075-306-811-251	VZTYP 変位センサー
400108615 / TM1-0075-306-811-104	VZTYP 変位センサー
400108612 / TM1-0075-305-811-251	VZTYP 変位センサー
TP1-0750-101-411-205	トランスデューサ
TH1-2250-102-423-205	ポジショントランスデューサ
TP1-1400-101-423-102	トランスデューサ
TP1-0100-101-222-102	トランスデューサ
TEX-0200-415-002-205	リニアポテンシオメータ
TH1-1425-104-423-102	トランスデューサ
RSM-2832-005-213-202	角度センサー
400026209 / LWG-0225-000-201	トランスデューサ
RFC-4853-609-121-201	ロータリーセンサー




商品名	説明
SSP-2801-100-002-002	
400026318 / LWX-0450-003-101	トランスデューサ
400054064 / MUP-160-4	ポテンシオメータ用測定コンバータ
TP1-0650-101-411-205	トランスデューサ
LWH-0750 #024530	
400024514 / LWH-0360	ポジショントランスデューサ
RSC 2832-618-111-202	ロータリーセンサー非接触
TH1-0150-102-411-201	ポジショントランスデューサ
RSC-2832-636-121-501	ロータリーセンサー
RSC-2801-636-212-201	角度センサー
400005638 / EEM 33-93	
400056058 / Z-TP1-S01-0400	
TLH 650 Nr.025279	変位センサー
TEX-0150-421-002-202	ポジショントランスデューサ
LWH-0800	変位センサー
TP1-0850-101-423-102	トランスデューサ
TE1 0150 101 411 101	
TE1-0150-101-421-101	リニア位置センサー
LS1 0150 001 411 101	
LS1 0150 001 413 101	
LS1 0150 001 421 101	
400054102 / MUW-200-1	ポテンシオメータ変換器
TP1-0400-101-411-205	変位センサー
TH1-1100-104-423-102	
TP1-1250-101-A14-107	トランスデューサ
400026324 / LWX-0600-003-101	変位センサー
TP1-0200-101-423-101	トランスデューサ
005678 / Z-R50	ローラーヘッド
TH1-0325-102-411-203	
RFC-4853-736-343-251	角度センサー
TE1-0150-101-412-202	ショートストロークトランスデューサ
GP-10-P-4501-A502	伝送ポテンシオメータ
TEX-0050-413-002-202	変位センサー
400026509 / LWX-0225-004-101	トランスデューサ
TP1-0200-101-423-201	線形変位センサー
400024548 / LWH-1200	ポジショントランスデューサ
RFC-4853-603-111-206	
RFC-4851-636-121-501	角度センサー
RFC 4851-812-224-421	角度センサー
RSC 2841-610-121-201	ロータリーセンサー
TP1-1200-101-411-102	変位センサー
RSM-2832-003-113-202	角度位置センサー
P-6501-A502	円形ポテンシオメータ
RFD-4021-606-211-401	ロータリーセンサー
TLH 650 TYPE 002517	リニアトランスデューサ



商品名	説明
400056088 / Z-RFC-P31	フラットポジションセンサー
TH1-1500-102-423-102	トランスデューサ
RFC-4852-214-614-202	角度センサー
RSA-3202-214-614-521	角度センサー
TP1-0350-101-411-102	トランスデューサ
EEM-33-77	5ピン、アングル付き、シールド付き、IP67
400009113 / GP-10-P-6501-A502	伝送ポテンショメータ
RSC 2821-610-111-201	ロータリーセンサー
LS1-0025-002-423-202	センサー
TP1-0300-101-411-102	トランスデューサ
TH1-1450-102-423-102	
Nr. 400024507 Type LWH-0175	変位センサー
RSC-2831-618-121-202	
EEM 33-84 M16/ 400005627	接続テクノロジー
P/N: 400107044, Type: TRS-0010-101	ショートストロークトランスデューサ
RFC-4853-607-122-206	ロータリーセンサー
RFC-4853-607-122-210	
TE1-0100-102-412-101	変位センサー
400024518 / LWH-0450	トランスデューサ
TH1-0200-103-411-102	変位センサー
ART.NR.:023206 / TYP: T-0150	
TE1-0100-102-411-101	変位センサー
RFE-3201-636-341-521	
400104754 / Z-RFC-P19	ネジ位置センサー
TH1-0050-102-211-101	トランスデューサ
Z-TP1-P07 / 005694	
EEM33-92 / 005637	
F-NR.: 114296/012 / RSC 2801-610-112-210	
TP1-0650-101-423-205	
400020AA4 / RSC-2831-606-111-201	角度センサー
4853 609 322 256	
TH1-0200-901-107	リニアインシリンダ位置センサ
400024511 / LWH-0275	トランスデューサポテンショメトリック
TP1 0250 101 411 205	
TP1-1200-101-423-102	リニアタッチレス位置センサー
TP1-1200-101-841-102	リニアタッチレス位置センサー
RSC-2802-609-112-202	角度センサー、非接触-最大360°まで絶対測定
TP1-2750-101-211-102	トランスデューサ
TP1-0050-101-421-101	変位センサー
TEX-0010-421-002-202	位置トランスデューサ
RSM-2862-003-211-201	角度センサー
TM1-0700-306-821-104	トランスデューサ
TH1-0050-102-423-203	




商品名	説明
TEX-0010-428-002-101	変位センサー
RFC-4853-606-111-202	VZTYP アングルセンサー
RFC-4853-609-111-202	角度センサー
IPX-7901-105-120-402	120°アングルセンサー
400107035	リニアポテンショメータ
400005605	コネクタ
RFC 4801 207 539 302	角度センサー
400026424	
400058100 / Z-G60	
TP1-1800-101-841-102	トランスデューサ
400024561 / LWH-0350	
RSA-3201-809-344-521	角度センサー
IPX-7901-101-120-402	120° 角度センサーレド
TP1-0500-101-423-101	トランスデューサ
RSC-2841-618-121-206	角度センサー、非接触
TP1-1400-101-211-102	トランスデューサ
TP1-1800-101-211-102	トランスデューサ
TP1-2250-101-211-102	トランスデューサ
5431700017	
P/N: 400005324, Type: F-210-1G	非接触位置センサー、誘導式
Z-RSA-M01/ 400105062	センサー取り付けブラケット
p/n: 400023265, Type: TR-0025-1	ウェイボタン
RFC-4851-214-A11-551	角度センサー
TP1-0300-101-411-101	
LWX-0300-101 (400026312)	位置センサー、電位差測定
TEX-0125-411-002-202	位置センサー、電位差測定
RSM-2832-006-121-206	マルチターンセンサー
TEX 0010-421-002-101	位置トランスデューサ
TEX-0100-415-202	位置センサー、電位差測定
LWG-0225 / 400026109	トランスデューサ
TE1-0050-102-421-202	トランスデューサ
400056308	ベイパック
TEX-0300-413-002-205	位置トランスデューサ
TEX-150-413-002-101	位置トランスデューサ
TH1-0525-102-423-102	エンコーダー
400056127 / EEM-33-27	コネクタ
TP1-0300-101-423-101	トランスデューサ
RFC-4851-636-211-202	角度センサー
P/N: 400026110, Type: LWG-0250	プッシュロッドとロッドエンド付き位置センサー、M12x1プラグ
RFC-4853-636-341-251	センサー
RFC4801-608-321-251	
RFC4851-618-321-252	
IPX 7901-101-350-101	角度センサー
400002220/ P-2201-S0031	
RSM-2802-016-112-202	マルチターンセンサー




商品名	説明
RFC-4852-604-341-260	ロータリーセンサー
025335 / TLH 875	位置トランスデューサ
RSC-2821-609-211-201	センサー
RFC 4801-624-121-202	ロータリーセンサー
P/N: 400005617, Type: EEM-33-64	
TP1-0250-101-411-101	トランスデューサ
TP1-0700-101-411-102	VZTYP ポジションセンサー
TP1-0100-101-211-101	リニアメーター
400037209 / TX2-0250-716-002-202	位置トランスデューサ
RSC-2841-609-121-501	
P/N: 400065111, Type: PRS-25-A502	回転抵抗素子
TP1-0800-101-423-101	位置センサー、非接触、TP1シリーズ
TEX-0250-415-002-101	プッシュロッド
RSC-3202-836-224-521	角度センサー
RSC 2802-610-111-930	非接触角度センサー
TH1-0100-102-101	トランスデューサ
P/N: 124883-2106 Type: Z-TH1-P19	
TP1-2750-101-423-102	
TP1-2000-101-423-102	
TP1-2500-101-211-102	
TP1-3250-101-423-102	
TEX 0050-615-002-101	トランスデューサ
TP1-1250-101-411-205	
P/N: 400010040, Type: IPE-6501-S0055	角度センサー
TP1-0300-101-423-205	トランスデューサ
TH1-1000-102-423-102	トランスデューサ
RSM-2862-007-113-202	マルチターンセンサー
RFC 4801-622-121-501	
9418	位置トランスデューサ
RFC-4851-622-121-501	角度センサー
TP1-0100-101-423-102 /202599	
RFC-4851-612-121-206	角度センサー、非接触
TP1-0400-101-423-101	トランスデューサ
RSC-2841-736-213-202	角度センサー
4801-734-353-411	センサー
TP1 0850 101 411 205	磁歪式位置定規
RSA-3201-836-324-521	角度センサー
400037304 / TX2-0100-717-002-101	トランスデューサ
RSC-2831-636-211-201	角度センサー、非接触
TE1-0100-102-421-101	トランスデューサ
400010004 / IP-6501-G252	ポテンショメータ
400024526 / LWH-0650	トランスデューサ電位差測定
RSA-3201-803-224-521	角度センサー




商品名	説明
TP1-1100-101-411-205 (166964 / 17460043)	
400037203 / TX2-0075-716-002-202	位置トランスデューサ
RFC 4801-618-321-252	センサー
TH1-0100-102-423-102	トランスデューサ
TP1-0500-101-423-205	トランスデューサ
TP1-1500-101-414-113	センサー
400025383 / TLH-2500	リニア位置トランスデューサ
402516617	
RFC-4853-636-111-202	角度センサー
RFC-4853-718-323-251	
RFC-4851-603-111-201	ロータリーセンサータッチレス
RFC 4801-607-122-206 Nr.118870.026	角度センサー、非接触、RFCシリーズ
RFC-4853-636-321-551	VZタイプ角度センサー
RFE-3200	
RFC 4801-607-122-206	ロータリーセンサー
RFE-3201-214-611-521	
RFC-4852-214-621-202	
RFC-4852-214-611-202	
RFC-4853-636-351-251	
RFD-4021-736-213-411	
Z-RFC-P20	
400043502 / LFP-0050-001-001-001	変位センサー
RFC-4853-736-353-251	
RFC-4801-612-111-202	ロータリーセンサー
400005629 / EEM-33-86	コネクタシステム
TH1-0600-102-411-102	
TH1-0600-102-411-205	
400106371 / EEM-33-50	
400106373 / EEM-33-52	
400056136 / EEM-33-36	
400056139 / EEM-33-39	
400056074 / Z-RFC-P23	ポジションマーカー
400105041 / Z-RFC-P43	ポジションマーカー
TLH-1000	パステイカー
TH1 1650 102 423 101	トランスデューサ
TP1-0400-101-411-101	トランスデューサ
TP1-0100-101-411-102 (100 MM)	トランスデューサ
400026420 / LWX-0500-003-201	トランスデューサ
TH1-0250-102-411-101	M16 コネクター 0-10 ボルト出力 250 ミリメートルストロークセンサー
SP2801 100.002.002	
SP-2857-S0002	電位差角度センサー
LS1-0025-002-423-101	
RFC 4853 605 111 932	




商品名	説明
TH1-0200-104-A31-107	
TH1-0525-104-A31-107	
400105076	
400056090	
RSC 2841-718-213-202	センサー
RSM 2871-003-112-201	マルチターンセンサー
RSM 2871-003-112-202	マルチターンセンサー
RSM 2871-003-112-206	マルチターンセンサー
RSM 2871-003-112-210	マルチターンセンサー
RSM 2871-003-112-220	マルチターンセンサー
RSM 2871-003-112-501	マルチターンセンサー
400011022 / AW-360-ZE-11	ロータリーセンサー
RFC-4801-603-111-206	
TH1-2500-102-423-102	トランスデューサ
M12	コネクタ
085342/O	
RSM2832-010-223-206	
RFE-3201-636-321-521	ロータリーセンサー
RSM-2862-016-121-220	センサー
RSC-2801-605-111-206	
TEX 0200 421 002 101	トランスデューサ
TRS-0075-101	TRS-0075-101-スプリング式リニアポテンショメータ位置センサ分圧器 75mm 0.1% 5kOhm クランプマウントコネクタ、M8、3 ピン IP40 TRS
RSC 2841-636-121-202	角度センサー
RSC 2802-610-112-201	
400002161 / S-115	グラインダーセット
400002191 / PTN-150	並進抵抗素子
TEX-0300-415-002-202	位置トランスデューサ、
LWH-0225	パスセンサー
TLH 175 / 025272	
4853-606-321-401	
400005602 / EEM-33-56	コネクタ 2 m ケーブル付き
TP1-0750-101-423-102	線形位置および変位センサー
400049552 / TE1-0150-101-411-202	
RSC-2801-609-111-206	
P/N: 164-90-068 Type: SP-2841-308-000-001	
RSM-2832-016-112-501	
TP1-0150-101-411-102	
9333107495	サーボボットとボードアッシー。
A290AZ000000341	
TP1 0800 101 423 102	トランスデューサ
IPE 6501 S0055	ポテンショメーター
SP2846 130 050 101	センサーポテンショメーター
SP2846-100-054-101	センサー




商品名	説明
RSC-2801-609-121-206	
TP1-0100-101-225-101	トランスデューサ
TRS-0050 Wegtaster Steckbar	
RFC-4853-622-321-551	
TEX-0200-413-002-202	変位センサー
P/N: 400105037, Type: Z-RFC-P41	位置センサー
RFC-4853-618-321-251	角度センサー
RSM-2841-016-121-206	角度センサー
LWH-0425	
400108799 / MUP-410-11	
TM1-1100-002-101	トランスデューサ
TM1-0950-305-811-251	
RFC-4853-636-321-401	角度センサー
LWG-0150 (112245/H)	
TEX-0200-415-002-101	
RFC 4851-609-212-206	回転センサー
TEX-0125-411-002-101	ウェガウフネマー
TX2-0025-716-002-101 B/N 185761	
RFC-4853-636-111-201	回転センサー
TRS-0050	
RSC-3101-636-732-903	
TH1-0750-102-423-102	ノボストリクティブ、マグネストリクティブ
RFD-4000	
RSM-2832-016-121-202	
RSC 2802-610-112-930	センサー / エンコーダー (名前プレートの写真から)
P.N 400037208 / Type: 1-TX2-0200-716-002-202	
RFC-4801-636321-501	
RFC 4852 214 A11 551	sensor
PTP-0050-311-002-001	ポテンシヨメトリック位置センサー
RFD-4021-812-214-421	角度センサー
RFC-4801-736-213-251	角度センサー
RFC-4801-618-111-202	角度センサー
LWH450	
TP1-0900-101-423-101	位置トランスデューサー
TP1-0900-101-423-101	ウェガウフネマー
RSC 2832-606-121-220	ウィンケルセンサー
TEX-0075-415-502-202	ウェガウフネマー
RSA-3201-612-321-521	
B02128 CT250	ポテンシヨメーター
400104102/RSM-2862-016-121-202	ウィンケルセンサー
TP1-1300-101-423-205	ウェガウフネマー
TF1-0100-001-A11-107	ウェガウフナー
400104344 / Z-TF1-P02	ガイド付き位置マーカープロファイル設計
RSA-3201-214-J13-521	角度センサー




商品名	説明
400023279 / TRS-0100-05	ショートストロークトランスデューサ
74140010	
TEX-0125-421-002-202	ウェガウフネーマー
RFC-48xx-6xx-342-xxx	Angle sensor surcharge
RFC-48xx-6xx-341-xxx	Angle sensor surcharge
RFX-6900	Contactless Angle Sensor
TM1-0550-xxx-xxx-xxx	Displacement Sensor
TM1-0125-xxx-xxx-xxx	Displacement Sensor
TM1-1500-xxx-xxx-xxx	Displacement Sensor
TH1-2450-xxx-xxx-xxx	Non-contact displacement sensor
RSX-79xx-6xx-xxx-252	Surcharge for Single-Channel Analog RSX-7900
TRS-0050-1-101	Displacement transducer up to 100 mm with continuous push rod
RFX-69xx-7xx-xxx-xxx	Partially Redundant Surcharge
TM1-0925-xxx-xxx-xxx	Displacement Sensor
TH1-2800-xxx-xxx-xxx	Non-contact displacement sensor
LS1-xxxx-xxx-xxx-202	LS1 Option
TS-0025-1-101	Displacement sensor up to 150 mm with continuous push rod
RFX-69xx-8xx-324-xxx	Fully Redundant Surcharge
RFC-48xx-6xx-322-xxx	Angle sensor surcharge
RSM-28xx-0xx-xxx-210	Analog configuration surcharge
TH1-3550-xxx-xxx-xxx	Non-contact displacement sensor
RFC-48xx-6xx-xxx-260	Angle sensor surcharge
TP1-xxxx-xxx-xxx-205	Cable
TH1-2900-xxx-xxx-xxx	Non-contact displacement sensor
TM1-1750-xxx-xxx-xxx	Displacement Sensor
Z-TP1-S01-0350	Push Rod
TM1-0100-xxx-xxx-xxx	Displacement Sensor
RSA-3201-xxx-xxx-xxx	Contactless angle sensor
RSX-79xx-2xx-xxx-301	Surcharge for Digital RSX-7900
RSX-79xx-8xx-xxx-xxx	Surcharge for Fully Redundant Analog RSX-7900
RSM-28xx-0xx-xxx-202	Analog configuration surcharge
RSA-32xx-7xx-xx-521	Connector option
RMB-3600	Non-contact angle sensor
RSA-32xx-6xx-xxx-xxx	Analog angle range option
TH1-2725-xxx-xxx-xxx	Non-contact displacement sensor
TH1-1800-xxx-xxx-xxx	Non-contact displacement sensor
TM1-0275-xxx-xxx-xxx	Displacement Sensor
RSX-79xx-6xx-xxx-551	Surcharge for Single-Channel Analog RSX-7900
RFC-48xx-6xx-122-xxx	Angle sensor surcharge
LS1-0200-xxx-xxx-xxx	Contactless Displacement Sensor
RSA-32xx-2xx-J5x-xxx	Digital output option
RFC-48xx-6xx-xxx-401	Angle sensor surcharge
RSA-32xx-7xx-xxx-xxx	Partially redundant angle range option
TP1-xxxx-xxx-21x-xxx	SSI interface
RSM-28xx-0xx-111-xxx	Analog configuration surcharge




商品名	説明
TF1-0600-xxx-xxx-xxx	Displacement Sensor
TH1-2200-xxx-xxx-xxx	Non-contact displacement sensor
TH1-2775-xxx-xxx-xxx	Non-contact displacement sensor
RSA-32xx-214-xxx-xxx	Digital angle range option
RFX-69xx-6xx-321-xxx	Single-channel Surcharge
RSA-32xx-7xx-343-xxx	Partially redundant analog output option
RFX-69xx-2xx-62x-xxx	Digital Surcharge
RFC-4861-xxx-xxx-xxx	Contactless angle sensor
TM1-0475-xxx-xxx-xxx	Displacement Sensor
TH1-3525-xxx-xxx-xxx	Non-contact displacement sensor
RSX-79xx-214-xxx-xxx	Surcharge for Digital RSX-7900
TH1-3025-xxx-xxx-xxx	Non-contact displacement sensor
RSX-7941-xxx-xxx-xxx	Heavy-Duty Angle Sensor
TM1-0250-xxx-xxx-xxx	Displacement Sensor
RFX-69xx-xxx-xxx-xxx	Minimum Quantity Surcharge
RFC-4802-xxx-xxx-xxx	Contactless angle sensor
RSX-79xx-6xx-322-xxx	Surcharge for Single-Channel Analog RSX-7900
TM1-1825-xxx-xxx-xxx	Displacement Sensor
TF1-xxxx-xxx-A11-xxx	TF1 Surcharge Option
RSM-28xx-0xx-xxx-201	Analog configuration surcharge
TM1-2000-xxx-xxx-xxx	Displacement Sensor
RFC-4863-xxx-xxx-xxx	Contactless angle sensor
RSX-79xx-6xx-321-xxx	Surcharge for Single-Channel Analog RSX-7900
RSM-28xx-2xx-x4x-436	Digital configuration surcharge
TF1-0300-xxx-xxx-xxx	Displacement Sensor
RSA-32xx-xxx-xxx-xxx	Initial costs
TP1-xxxx-xxx-111-xxx	Pulse interface
RSA-32xx-8xx-224-xxx	Redundant analog output option
RFC-48xx-7xx-xxx-411	Angle sensor surcharge
RFX-69xx-7xx-323-xxx	Partially Redundant Surcharge
TH1-3100-xxx-xxx-xxx	Non-contact displacement sensor
RFC-480x-xxx-xxx-xxx	Initial cost
TS-0100-101	Displacement sensor up to 150 mm with continuous push rod
RSX-7913-xxx-xxx-xxx	Heavy-Duty Angle Sensor
RFC-48xx-6xx-212-xxx	Angle sensor surcharge
TM1-1725-xxx-xxx-xxx	Displacement Sensor
TM1-1450-xxx-xxx-xxx	Displacement Sensor
RFC-48xx-7xx-xxx-270	Angle sensor surcharge
LS1-xxxx-xxx-xxx-101	LS1 Option
RFC-48xx-7xx-xxx-201	Angle sensor surcharge
RSA-3222-xxx-xxx-xxx	Contactless angle sensor
TM1-1250-xxx-xxx-xxx	Displacement Sensor
Z-TP1-S01-0600	Push Rod
Z-TP1-S01-0250	Push Rod
TM1-1200-xxx-xxx-xxx	Displacement Sensor




商品名	説明
RFC-48xx-6xx-xxx-201	Angle sensor surcharge
RSA-32xx-2xx-J1x-xxx	Digital output option
LWG-0375-000-201	Potentiometric Displacement Sensor
RSX-7943-xxx-xxx-xxx	Heavy-Duty Angle Sensor
TF1-xxxx-xxx-424-xxx	TF1 Surcharge Option
TM1-1075-xxx-xxx-xxx	Displacement Sensor
LWG-0275	Potentiometric Displacement Sensor
RSX-7947-xxx-xxx-xxx	Heavy-Duty Angle Sensor
LWG-0325	Potentiometric Displacement Sensor
Z-IPX-M21	Sensor Mounting Accessory
RFC-48xx-6xx-xxx-xxx	Angle sensor surcharge
RFC-48xx-7xx-xxx-251	Angle sensor surcharge
Z-TP1-S01-0125	Push Rod
RSA-32xx-6xx-352-xxx	Analog output option
RFX-69xx-6xx-xxx-xxx	Single-channel Surcharge
RSM-28xx-0xx-112-xxx	Analog configuration surcharge
Z-RFC-P22	Position encoder
RSA-32xx-2xx-62x-xxx	Digital output option
RFC-48xx-6xx-xxx-932	Angle sensor surcharge
TH1-1975-xxx-xxx-xxx	Non-contact displacement sensor
TM1-1550-xxx-xxx-xxx	Displacement Sensor
RSM-2862-xxx-xxx-xxx	Angle sensor
LS1-0025-xxx-xxx-xxx	Contactless Displacement Sensor
TF1-xxxx-xxx-xxx-106	TF1 Surcharge Option
RSX-79xx-8xx-xxx-352	Surcharge for Fully Redundant Analog RSX-7900
TH1-2425-xxx-xxx-xxx	Non-contact displacement sensor
RSM-28xx-214-xxx-xxx	Digital configuration surcharge
RFC-4864-xxx-xxx-xxx	Contactless angle sensor
TLH-0325	Displacement sensor without push rod
RSA-32xx-6xx-342-xxx	Analog output option
TF1-xxxx-xxx-A12-xxx	TF1 Surcharge Option
RSM-28xx-2xx-281-xxx	Digital configuration surcharge
TP1-xxxx-xxx-xxx-101	Connector
RSX-79xx-2xx-xxx-201	Surcharge for Digital RSX-7900
TF1-xxxx-xxx-613-xxx	TF1 Surcharge Option
RFC-48xx-7xx-xxx-552	Angle sensor surcharge
P-2501-345-253-001	Standard potentiometer, multiple (stackable)
RFC-48xx-6xx-xxx-251	Angle sensor surcharge
TP1-xxxx-xxx-8A1-xxx	Incremental (Quadrature)
RFC-48xx-6xx-xxx-552	Angle sensor surcharge
RSX-79xx-6xx-xxx-xxx	Surcharge for Single-Channel Analog RSX-7900
TF1-xxxx-xxx-219-xxx	TF1 Surcharge Option
TM1-1350-xxx-xxx-xxx	Displacement Sensor
TH1-3300-xxx-xxx-xxx	Non-contact displacement sensor
RSX-79xx-2xx-xxx-511	Surcharge for Digital RSX-7900



商品名	説明
TH1-2875-xxx-xxx-xxx	Non-contact displacement sensor
Z-G-04	Stainless steel ball joint head
TM1-1000-xxx-xxx-xxx	Displacement Sensor
TM1-0975-xxx-xxx-xxx	Displacement Sensor
TH1-2650-xxx-xxx-xxx	Non-contact displacement sensor
RFC-48xx-6xx-321-xxx	Angle sensor surcharge
P-2501-120-285-001	Standard potentiometer, multiple (stackable)
RFC-48xx-6xx-222-xxx	Angle sensor surcharge
RSM-28xx-xxx-xxx-xxx	Minimum quantity surcharge
TH1-2025-xxx-xxx-xxx	Non-contact displacement sensor
Z-TP1-S01-0200	Push Rod
TF1-xxxx-xxx-24x-xxx	TF1 Surcharge Option
RFC-48xx-6xx-xxx-202	Angle sensor surcharge
TH1-2350-xxx-xxx-xxx	Non-contact displacement sensor
TH1-2950-xxx-xxx-xxx	Non-contact displacement sensor
TM1-0150-xxx-xxx-xxx	Displacement Sensor
TH1-3000-xxx-xxx-xxx	Non-contact displacement sensor
P-2500	Potentiometric angle sensor
RFC-4853-xxx-xxx-xxx	Contactless angle sensor
RSA-32xx-2xx-66x-xxx	Digital output option
RSX-79xx-2xx-65x-xxx	Surcharge for Digital RSX-7900
RFC-4852-xxx-xxx-xxx	Contactless angle sensor
RFC-48xx-7xx-xxx-xxx	Angle sensor surcharge
TH1-2825-xxx-xxx-xxx	Non-contact displacement sensor
Z-PTP-S01	Push rod
TF1-xxxx-xxx-21x-xxx	TF1 Surcharge Option
RSM-28xx-2xx-141-xxx	Digital configuration surcharge
RSX-79xx-7xx-xxx-551	Surcharge for Partially Redundant Analog RSX-7900
RSA-32xx-6xx-xxx-521	Connector option
RSM-2801-xxx-xxx-xxx	Angle sensor
TH1-2225-xxx-xxx-xxx	Non-contact displacement sensor
TH1-2150-xxx-xxx-xxx	Non-contact displacement sensor
TM1-0400-xxx-xxx-xxx	Displacement Sensor
TM1-0575-xxx-xxx-xxx	Displacement Sensor
RFC-48xx-6xx-112-xxx	Angle sensor surcharge
RFX-69xx-2xx-66x-xxx	Digital Surcharge
TM1-0425-xxx-xxx-xxx	Displacement Sensor
RSM-28xx-2xx-x4x-432	Digital configuration surcharge
RFX-69xx-6xx-322-xxx	Single-channel Surcharge
TRS-0100-101	Displacement transducer up to 100 mm with continuous push rod
TP1-xxxx-xxx-A15-xxx	IO-Link
RFX-69xx-7xx-xxx-252	Partially Redundant Surcharge
TM1-1875-xxx-xxx-xxx	Displacement Sensor
RSX-79xx-2xx-66x-xxx	Surcharge for Digital RSX-7900
TH1-3225-xxx-xxx-xxx	Non-contact displacement sensor




商品名	説明
TM1-0875-xxx-xxx-xxx	Displacement Sensor
RFC-48xx-7xx-343-xxx	Angle sensor surcharge
TH1-1950-xxx-xxx-xxx	Non-contact displacement sensor
TM1-1575-xxx-xxx-xxx	Displacement Sensor
TH1-2550-xxx-xxx-xxx	Non-contact displacement sensor
RSA-3221-xxx-xxx-xxx	Contactless angle sensor
RSM-28xx-0xx-221-xxx	Analog configuration surcharge
RSA-32xx-8xx-324-xxx	Redundant analog output option
RFX-69xx-214-xxx-xxx	Digital Surcharge
LWG-0100-000-201	Potentiometric Displacement Sensor
RSX-79xx-2xx-61x-xxx	Surcharge for Digital RSX-7900
TRS-0075-05-101	Displacement transducer up to 100 mm with continuous push rod
TH1-2500-xxx-xxx-xxx	Non-contact displacement sensor
RSA-32xx-6xx-341-xxx	Analog output option
LS1-xxxx-xxx-413-xxx	LS1 Option
RSM-28xx-2xx-14x-xxx	Digital configuration surcharge
TF1-0200-xxx-xxx-xxx	Displacement Sensor
RSA-32xx-6xx-212-xxx	Analog output option
RSA-32xx-2xx-61x-xxx	Digital output option
RSA-32xx-2xx-65x-xxx	Digital output option
LWG-0400-000-201	Potentiometric Displacement Sensor
RSM-28xx-2xx-x4x-440	Digital configuration surcharge
RSM-28xx-2xx-241-xxx	Digital configuration surcharge
TF1-xxxx-xxx-23x-xxx	TF1 Surcharge Option
TH1-1825-xxx-xxx-xxx	Non-contact displacement sensor
TM1-0675-xxx-xxx-xxx	Displacement Sensor
TM1-1525-xxx-xxx-xxx	Displacement Sensor
TH1-2375-xxx-xxx-xxx	Non-contact displacement sensor
RSM-2831-xxx-xxx-xxx	Angle sensor
Z-TP1-S01-0500	Push Rod
TF1-xxxx-xxx-A32-xxx	TF1 Surcharge Option
TM1-1800-xxx-xxx-xxx	Displacement Sensor
TM1-1100-xxx-xxx-xxx	Displacement Sensor
TH1-3250-xxx-xxx-xxx	Non-contact displacement sensor
TM1-0350-xxx-xxx-xxx	Displacement Sensor
TH1-2100-xxx-xxx-xxx	Non-contact displacement sensor
TH1-3125-xxx-xxx-xxx	Non-contact displacement sensor
RFC-48xx-7xx-xxx-210	Angle sensor surcharge
TH1-2050-xxx-xxx-xxx	Non-contact displacement sensor
LS1-xxxx-xxx-414-xxx	LS1 Option
TM1-0375-xxx-xxx-xxx	Displacement Sensor
TM1-0900-xxx-xxx-xxx	Displacement Sensor
RSX-7917-xxx-xxx-xxx	Heavy-Duty Angle Sensor
Z-10-6.3	Adjustment knob
TP1-xxxx-xxx-xxx-210	Cable




商品名	説明
TS-0050-1-101	Displacement sensor up to 150 mm with continuous push rod
TH1-2700-xxx-xxx-xxx	Non-contact displacement sensor
TH1-1875-xxx-xxx-xxx	Non-contact displacement sensor
Z-TP1-S01-1000	Push Rod
TH1-3050-xxx-xxx-xxx	Non-contact displacement sensor
RFC-48xx-6xx-xxx-220	Angle sensor surcharge
TP1-xxxx-xxx-xxx-107	Connector
TS-0075-101	Displacement sensor up to 150 mm with continuous push rod
Z-G-03	Stainless steel ball joint head
TH1-2600-xxx-xxx-xxx	Non-contact displacement sensor
TRS-0050-05-101	Displacement transducer up to 100 mm with continuous push rod
RSA-32xx-6xx-211-xxx	Analog output option
RSA-32xx-6xx-321-xxx	Analog output option
TH1-3200-xxx-xxx-xxx	Non-contact displacement sensor
TM1-0650-xxx-xxx-xxx	Displacement Sensor
TH1-2275-xxx-xxx-xxx	Non-contact displacement sensor
TH1-1850-xxx-xxx-xxx	Non-contact displacement sensor
RSM-28xx-216-xxx-xxx	Digital configuration surcharge
RSA-32xx-7xx-223-xxx	Partially redundant analog output option
TH1-3600-xxx-xxx-xxx	Non-contact displacement sensor
TF1-xxxx-xxx-633-xxx	TF1 Surcharge Option
RSX-79xx-7xx-xxx-xxx	Surcharge for Partially Redundant Analog RSX-7900
TF1-0800-xxx-xxx-xxx	Displacement Sensor
RSX-79xx-7xx-323-xxx	Surcharge for Partially Redundant Analog RSX-7900
RSA-3200	Non-contact angle sensor
RSA-32xx-2xx-J7x-xxx	Digital output option
RFX-69xx-2xx-xxx-201	Digital Surcharge
RFC-48xx-6xx-352-xxx	Angle sensor surcharge
TM1-1325-xxx-xxx-xxx	Displacement Sensor
RFC-48xx-xxx-xxx-xxx	Minimum quantity surcharge
RFC-48xx-6xx-xxx-501	Angle sensor surcharge
RSA-32xx-8xx-xxx-521	Connector option
TF1-xxxx-xxx-61x-xxx	TF1 Surcharge Option
Z-TP1-S01-0100	Push Rod
RSM-2861-xxx-xxx-xxx	Angle sensor
RFC-48xx-7xx-xxx-202	Angle sensor surcharge
RFX-69xx-8xx-xxx-651	Fully Redundant Surcharge
TS-0050-05-101	Displacement sensor up to 150 mm with continuous push rod
LS1-xxxx-xxx-412-xxx	LS1 Option
Z-TP1-S01-xxxx	Push Rod
TM1-0700-xxx-xxx-xxx	Displacement Sensor
RFX-69xx-2xx-61x-xxx	Digital Surcharge
TP1-xxxx-xxx-A12-xxx	IO-Link
TM1-0600-xxx-xxx-xxx	Displacement Sensor
LWG-0130-000-201	Potentiometric Displacement Sensor




商品名	説明
TH1-2975-xxx-xxx-xxx	Non-contact displacement sensor
LS1-xxxx-xxx-424-xxx	LS1 Option
RFX-6901-xxx-xxx-xxx	Contactless Angle Sensor
TF1-0400-xxx-xxx-xxx	Displacement Sensor
RSM-28xx-0xx-122-xxx	Analog configuration surcharge
TH1-3625-xxx-xxx-xxx	Non-contact displacement sensor
TM1-0075-xxx-xxx-xxx	Displacement Sensor
TF1-xxxx-001-xxx-xxx	TF1 Surcharge Option
LS1-xxxx-xxx-421-xxx	LS1 Option
RSA-32xx-6xx-322-xxx	Analog output option
TH1-1900-xxx-xxx-xxx	Non-contact displacement sensor
P-4500	Potentiometric angle sensor
RSC-3200	Non-contact angle sensor
TM1-1400-xxx-xxx-xxx	Displacement Sensor
RFC-48xx-7xx-xxx-220	Angle sensor surcharge
TM1-1175-xxx-xxx-xxx	Displacement Sensor
RFC-48xx-7xx-xxx-206	Angle sensor surcharge
TH1-3575-xxx-xxx-xxx	Non-contact displacement sensor
RSA-32xx-2xx-xxx-521	Connector option
TH1-2000-xxx-xxx-xxx	Non-contact displacement sensor
TS-0025-101	Displacement sensor up to 150 mm with continuous push rod
RSA-32xx-2xx-J6x-xxx	Digital output option
TH1-2125-xxx-xxx-xxx	Non-contact displacement sensor
RSA-32xx-8xx-xxx-xxx	Redundant angle range option
TH1-2300-xxx-xxx-xxx	Non-contact displacement sensor
RFX-69xx-7xx-xxx-551	Partially Redundant Surcharge
LS1-xxxx-002-xxx-xxx	LS1 Option
TH1-1925-xxx-xxx-xxx	Non-contact displacement sensor
TF1-xxxx-xxx-423-xxx	TF1 Surcharge Option
TM1-1275-xxx-xxx-xxx	Displacement Sensor
TH1-3500-xxx-xxx-xxx	Non-contact displacement sensor
TP1-xxxx-xxx-841-xxx	Incremental (Quadrature)
LS1-0075-xxx-xxx-xxx	Contactless Displacement Sensor
TM1-1025-xxx-xxx-xxx	Displacement Sensor
RSA-32xx-7xx-353-xxx	Partially redundant analog output option
TP1-xxxx-xxx-A13-xxx	IO-Link
RFX-69xx-2xx-xxx-611	Digital Surcharge
TF1-0500-xxx-xxx-xxx	Displacement Sensor
Z-RFC-P28	Screw position encoder
TF1-1000-xxx-xxx-xxx	Displacement Sensor
TH1-2750-xxx-xxx-xxx	Non-contact displacement sensor
TH1-3150-xxx-xxx-xxx	Non-contact displacement sensor
LWG-0200-000-201	Potentiometric Displacement Sensor
RSM-28xx-0xx-223-xxx	Analog configuration surcharge
TP1-xxxx-101-xxx-xxx	Standard design




商品名	説明
P-2501-120-385-001	Standard potentiometer, multiple (stackable)
TF1-xxxx-xxx-212-xxx	TF1 Surcharge Option
TH1-2250-xxx-xxx-xxx	Non-contact displacement sensor
RSM-2821-xxx-xxx-xxx	Angle sensor
TF1-xxxx-xxx-A31-xxx	TF1 Surcharge Option
RFC-4862-xxx-xxx-xxx	Contactless angle sensor
TM1-1975-xxx-xxx-xxx	Displacement Sensor
TM1-0050-xxx-xxx-xxx	Displacement Sensor
RFC-48xx-6xx-211-xxx	Angle sensor surcharge
RFX-69xx-8xx-xxx-xxx	Fully Redundant Surcharge
TM1-1225-xxx-xxx-xxx	Displacement Sensor
RFC-48xx-6xx-111-xxx	Angle sensor surcharge
RSM-2832-xxx-xxx-xxx	Angle sensor
RSX-79xx-7xx-xxx-252	Surcharge for Partially Redundant Analog RSX-7900
RFC-48xx-7xx-223-xxx	Angle sensor surcharge
RSA-32xx-8xx-214-xxx	Redundant analog output option
TM1-0825-xxx-xxx-xxx	Displacement Sensor
TP1-xxxx-xxx-61x-xxx	CANopen
RFX-69xx-6xx-xxx-551	Single-channel Surcharge
LS1-xxxx-xxx-411-xxx	LS1 Option
RFC-4851-xxx-xxx-xxx	Contactless angle sensor
TP1-xxxx-xxx-423-xxx	Current output
RFX-69xx-8xx-xxx-352	Fully Redundant Surcharge
TM1-0625-xxx-xxx-xxx	Displacement Sensor
Z-TP1-S01-0075	Push Rod
LWG-0325-000-201	Potentiometric Displacement Sensor
Z-TP1-S01-2000	Push Rod
TH1-3425-xxx-xxx-xxx	Non-contact displacement sensor
RSA-32xx-7xx-213-xxx	Partially redundant analog output option
TM1-1925-xxx-xxx-xxx	Displacement Sensor
Z-RFC-P18	Screw position encoder
TM1-0300-xxx-xxx-xxx	Displacement Sensor
LS1-0100-xxx-xxx-xxx	Contactless Displacement Sensor
TH1-2625-xxx-xxx-xxx	Non-contact displacement sensor
TM1-0175-xxx-xxx-xxx	Displacement Sensor
RFC-48xx-6xx-xxx-551	Angle sensor surcharge
TF1-0900-xxx-xxx-xxx	Displacement Sensor
RSM-28xx-0xx-xxx-xxx	Analog configuration surcharge
RFC-48xx-6xx-xxx-210	Angle sensor surcharge
TH1-3325-xxx-xxx-xxx	Non-contact displacement sensor
TLH-0425	Displacement sensor without push rod
TM1-1850-xxx-xxx-xxx	Displacement Sensor
TM1-1700-xxx-xxx-xxx	Displacement Sensor
TP1-xxxx-xxx-xxx-106	Connector
TRS-0100-05-101	Displacement transducer up to 100 mm with continuous push rod



商品名	説明
RSM-2802-xxx-xxx-xxx	Angle sensor
TM1-0750-xxx-xxx-xxx	Displacement Sensor
RSM-28xx-2xx-24x-xxx	Digital configuration surcharge
RSM-28xx-0xx-xxx-501	Analog configuration surcharge
LS1-xxxx-xxx-422-xxx	LS1 Option
RSM-28xx-2xx-xxx-531	Digital configuration surcharge
TS-0150-101	Displacement sensor up to 150 mm with continuous push rod
TM1-0225-xxx-xxx-xxx	Displacement Sensor
RSA-32xx-7xx-323-xxx	Partially redundant analog output option
SP-2800	Potentiometric angle sensor
RFX-69xx-6xx-xxx-252	Single-channel Surcharge
RSM-28xx-2xx-28x-302	Digital configuration surcharge
RSA-32xx-2xx-J3x-xxx	Digital output option
TP1-xxxx-xxx-xxx-103	Connector
TF1-xxxx-xxx-xxx-107	TF1 Surcharge Option
TP1-xxxx-xxx-421-xxx	Current output
RFC-48xx-7xx-xxx-256	Angle sensor surcharge
TP1-xxxx-xxx-A33-xxx	IO-Link
TM1-0800-xxx-xxx-xxx	Displacement Sensor
RSA-32xx-6xx-222-xxx	Analog output option
TR/TRS	Resistance element
RSA-32xx-6xx-221-xxx	Analog output option
TP1-xxxx-xxx-22x-xxx	SSI interface
TP1-xxxx-xxx-A32-xxx	IO-Link
RFC-48xx-6xx-xxx-270	Angle sensor surcharge
RSM-2800	Non-contact angle sensor
RFX-690x-xxx-xxx-xxx	Initial Cost
TRS-0025-1-101	Displacement transducer up to 100 mm with continuous push rod
P-2501-345-353-001	Standard potentiometer, multiple (stackable)
TP1-xxxx-xxx-63x-xxx	CANopen
RFC-48xx-6xx-221-xxx	Angle sensor surcharge
TM1-1150-xxx-xxx-xxx	Displacement Sensor
RFC-4854-xxx-xxx-xxx	Contactless angle sensor
LS1-xxxx-001-xxx-xxx	LS1 Option
TM1-1650-xxx-xxx-xxx	Displacement Sensor
TF1-xxxx-xxx-214-xxx	TF1 Surcharge Option
TP1-xxxx-xxx-121-xxx	Pulse interface
RFC-48xx-7xx-xxx-551	Angle sensor surcharge
RSX-79xx-2xx-xxx-611	Surcharge for Digital RSX-7900
RFC-48xx-7xx-323-xxx	Angle sensor surcharge
TM1-0325-xxx-xxx-xxx	Displacement Sensor
TS-0100-05-101	Displacement sensor up to 150 mm with continuous push rod
RSX-79xx-2xx-62x-xxx	Surcharge for Digital RSX-7900
TM1-0200-xxx-xxx-xxx	Displacement Sensor
LS1-xxxx-xxx-423-xxx	LS1 Option



商品名	説明
RSX-7911-xxx-xxx-xxx	Heavy-Duty Angle Sensor
Z-RFC-P47	Position encoder
RSA-32xx-8xx-344-xxx	Redundant analog output option
TP1-xxxx-xxx-A14-xxx	IO-Link
TM1-1050-xxx-xxx-xxx	Displacement Sensor
TH1-2675-xxx-xxx-xxx	Non-contact displacement sensor
EEM-33-24	Connection cable
TM1-1300-xxx-xxx-xxx	Displacement Sensor
TM1-1425-xxx-xxx-xxx	Displacement Sensor
TH1-2175-xxx-xxx-xxx	Non-contact displacement sensor
TM1-1625-xxx-xxx-xxx	Displacement Sensor
Z-PTP-B01	Pack, 4 clamping clips
TF1-0100-xxx-xxx-xxx	Displacement Sensor
RFC-48xx-7xx-xxx-501	Angle sensor surcharge
RSX-79xx-8xx-324-xxx	Surcharge for Fully Redundant Analog RSX-7900
RFC-48xx-6xx-xxx-252	Angle sensor surcharge
TH1-2575-xxx-xxx-xxx	Non-contact displacement sensor
TH1-2525-xxx-xxx-xxx	Non-contact displacement sensor
RSX-79xx-xxx-xxx-xxx	Surcharge for Special Characteristic Curve
LS1-0150-xxx-xxx-xxx	Contactless Displacement Sensor
RSX-79xx-8xx-xxx-651	Surcharge for Fully Redundant Analog RSX-7900
RFC-48xx-7xx-213-xxx	Angle sensor surcharge
TP1-xxxx-xxx-211-xxx	SSI interface
TH1-2400-xxx-xxx-xxx	Non-contact displacement sensor
RFX-69xx-2xx-65x-xxx	Digital Surcharge
TS-0075-05-101	Displacement sensor up to 150 mm with continuous push rod
Z-TP1-S01-0150	Push Rod
TM1-1775-xxx-xxx-xxx	Displacement Sensor
RSM-28xx-0xx-222-xxx	Analog configuration surcharge
TH1-2325-xxx-xxx-xxx	Non-contact displacement sensor
RSA-32xx-2xx-J2x-xxx	Digital output option
TM1-1900-xxx-xxx-xxx	Displacement Sensor
RSX-7900	Non-contact angle sensor
TFD-4000	Contactless displacement sensor
RSA-32xx-8xx-354-xxx	Redundant analog output option
TP1-xxxx-xxx-416-xxx	Voltage output
TM1-0725-xxx-xxx-xxx	Displacement Sensor
LWG-0275-000-201	Potentiometric Displacement Sensor
TF1-xxxx-xxx-xxx-102	TF1 Surcharge Option
RSM-2841-xxx-xxx-xxx	Angle sensor
RFC-48xx-7xx-353-xxx	Angle sensor surcharge
TH1-3400-xxx-xxx-xxx	Non-contact displacement sensor
TM1-0850-xxx-xxx-xxx	Displacement Sensor
TP1-xxxx-xxx-112-xxx	Pulse interface
TM1-0775-xxx-xxx-xxx	Displacement Sensor



商品名	説明
Z-TP1-S01-0300	Push Rod
RFC-48xx-6xx-xxx-206	Angle sensor surcharge
TP1-xxxx-xxx-xxx-102	Connector
TM1-0525-xxx-xxx-xxx	Displacement Sensor
TP1-xxxx-xxx-xxx-113	Connector
RFX-69xx-2xx-xxx-301	Digital Surcharge
RSA-3202-xxx-xxx-xxx	Contactless angle sensor
TM1-0450-xxx-xxx-xxx	Displacement Sensor
RSA-32xx-6xx-351-xxx	Analog output option
TM1-0500-xxx-xxx-xxx	Displacement Sensor
TM1-1125-xxx-xxx-xxx	Displacement Sensor
RSM-28xx-2xx-x4x-450	Digital configuration surcharge
TH1-3075-xxx-xxx-xxx	Non-contact displacement sensor
TH1-2850-xxx-xxx-xxx	Non-contact displacement sensor
Z-TP1-S01-1500	Push Rod
RSM-28xx-2xx-282-xxx	Digital configuration surcharge
RSM-28xx-0xx-113-xxx	Analog configuration surcharge
TF1-xxxx-xxx-411-xxx	TF1 Surcharge Option
RSM-28xx-0xx-121-xxx	Analog configuration surcharge
TH1-3275-xxx-xxx-xxx	Non-contact displacement sensor
TH1-2475-xxx-xxx-xxx	Non-contact displacement sensor
LS1-0050-xxx-xxx-xxx	Contactless Displacement Sensor
TF1-xxxx-xxx-22x-xxx	TF1 Surcharge Option
TH1-3375-xxx-xxx-xxx	Non-contact displacement sensor
TP1-xxxx-xxx-A11-xxx	IO-Link
TP1-xxxx-xxx-113-xxx	Pulse interface
TF1-0700-xxx-xxx-xxx	Displacement Sensor
RSM-28xx-0xx-212-xxx	Analog configuration surcharge
TH1-3350-xxx-xxx-xxx	Non-contact displacement sensor
TM1-1950-xxx-xxx-xxx	Displacement Sensor
RSM-28xx-0xx-213-xxx	Analog configuration surcharge
TS-0150-05-101	Displacement sensor up to 150 mm with continuous push rod
TM1-1475-xxx-xxx-xxx	Displacement Sensor
TP1-xxxx-xxx-xxx-108	Connector
TP1-xxxx-xxx-422-xxx	Current output
TH1-3475-xxx-xxx-xxx	Non-contact displacement sensor
T/TS	Resistance element
TM1-1375-xxx-xxx-xxx	Displacement Sensor
RSM-28xx-0xx-211-xxx	Analog configuration surcharge
RSB-3600	Non-contact angle sensor
RFC-48xx-7xx-xxx-252	Angle sensor surcharge
TM1-1675-xxx-xxx-xxx	Displacement Sensor
TP1-xxxx-xxx-414-xxx	Voltage output
RSM-28xx-0xx-xxx-206	Analog configuration surcharge
RSM-2871-xxx-xxx-xxx	Angle sensor



商品名	説明
TP1-xxxx-xxx-A34-xxx	IO-Link
TP1-xxxx-xxx-A31-xxx	IO-Link
TP1-xxxx-xxx-66x-xxx	CANopen
TP1-xxxx-xxx-891-xxx	Incremental (Quadrature)
TM1-0950-xxx-xxx-xxx	Displacement Sensor
TP1-xxxx-xxx-861-xxx	Incremental (Quadrature)
RSM-28xx-0xx-xxx-220	Analog configuration surcharge
TH1-2075-xxx-xxx-xxx	Non-contact displacement sensor
RFC-48xx-6xx-xxx-256	Angle sensor surcharge
TP1-xxxx-xxx-871-xxx	Incremental (Quadrature)
TH1-2925-xxx-xxx-xxx	Non-contact displacement sensor
TM1-1600-xxx-xxx-xxx	Displacement Sensor
RFC-48xx-7xx-xxx-260	Angle sensor surcharge
TP1-xxxx-xxx-A35-xxx	IO-Link
SP-2801-308-000-002	Sensor Potentiometer
TH1-3450-xxx-xxx-xxx	Non-contact displacement sensor
RFC-48xx-6xx-351-xxx	Angle sensor surcharge
TF1-xxxx-xxx-63x-xxx	TF1 Surcharge Option
TH1-3175-xxx-xxx-xxx	Non-contact displacement sensor
TP1-xxxx-xxx-xxx-105	Connector
TF1-xxxx-xxx-412-xxx	TF1 Surcharge Option
TP1-xxxx-xxx-424-xxx	Current output
RFX-69xx-2xx-xxx-511	Digital Surcharge
P-2200	Potentiometric angle sensor
TP1-xxxx-xxx-xxx-203	Cable
TP1-xxxx-xxx-xxx-201	Cable
TP1-xxxx-xxx-65x-xxx	CANopen
TP1-xxxx-xxx-411-xxx	Voltage output
P-2501-240-286-001	Standard potentiometer, multiple (stackable)
P-6500	Potentiometric angle sensor
RSM 2832-006-111-202	
P/N: 400056044, Type: Z-TH1-P21	シリンダー型磁気浮遊体
TEX-0050-413-002-101	ウェガウフネマー